

OACIS

Open Architecture Control Integrated System

Function Description

Version 01.71



www.atainc.com

ata@atainc.com

All Rights Reserved

CONTENTS

I. CONFIGURATION	4
A. PROGRAM INFORMATION.....	4
B. PROGRAM HOME POSITION.....	4
C. GLOBAL VARIABLES and SYSTEM VARIABLES	4
II. MOVE.....	6
A. Move to Position	6
B. Move to Load.....	6
C. Move to DI	7
D. Move to Press.....	8
E. Disable.....	8
F. Move to Program Home	9
G. Move to Position by Var	9
H. Move to Position by Var #2	10
I. Dynamic Move to Position	10
J. Set As Home	12
K. Move to AI	12
L. Move to Load by Var	13
M. Move to Bottom	14
N. Move to Load by Var #2	15
O. Move to Position with Limited Load.....	17
P. Start Hold Load / End Hold Load.....	18
Q. Deactivate.....	18
R. Move to Load by Var #3	19
III. SIGNAL.....	20
A. Set AI or Position.....	20
B. Set DO.....	20
C. Reset All DO.....	20
D. Set Status Binary.....	21
E. Set Signal Filter	21
F. Set DO by Signal.....	22
G. Set As Abs Value	22
H. Set AI or Position by Var	23
I. Set As Abs Value by Var	23
J. Send Out Data.....	23
IV. SEQUENCE	25
A. Jump Tag.....	25
B. Jump to Step	25
C. Jump to Step by DI	25
D. Jump by Condition.....	26
E. Jump by Condition #2.....	27
F. Jump by Multi Conditions	27
G. Loop Start.....	28
H. Loop End	29
I. Wait to DI.....	29
J. Delay	29

K. Wait to Pause	30
L. Program End	30
V. MEASURE.....	31
A. Measure AI or Position	31
B. DAQ	31
C. DAQ 2	33
D. DAQD	34
E. DAQA	36
F. CAPTURE	38
G. Count DI	39
VI. ANALYSIS	40
A. Analysis MinMaxAve	40
B. Analysis Turning Torque #1	41
C. Analysis Press #1	42
D. Analysis Press #2	43
E. Analysis Fx	45
F. Linear Regression	46
G. Linear Regression #2	47
H. Find Cross Point	47
I. Analysis Load Drop	48
J. Find Cross Point #2	49
K. Assign Analysis GV	50
L. Find Point	51
VII. GAGE.....	52
A. Gaging Global Variable	52
B. Gaging AI or Position	53
C. Gaging Global Variable by Var	53
D. Check Global Variable	54
E. Gaging DAQ by Teaching	55
VIII. MATH	61
A. Reset All Global Variables	61
B. Set Global Variable	61
C. Set Multi GVs	61
D. Math1	62
E. Math2	62
F. Math3	63
G. Math4	64
H. MathA	64
I. Slope	65
J. Round	65
K. Find GV	66
IX. FIELDBUS.....	67
A. Capture Serial From Fieldbus	67
REVISION	68

I. CONFIGURATION

#Note: It is a separately used Program Configuration (different from “System Configuration”) per one program. And it is not a “Function”. But it is to be used in following Functions.

A. PROGRAM INFORMATION

CONFIGURATION			MOVE	SIGNAL	SEQUENCE	MI
PROGRAM INFORMATION						
PROGRAM NUMBER	PROGRAM NAME	DATETIME				
0	my New Program	100704232928				

- **Program Number:** It is to be one of 1 ~ 120. Only one program is allowed for the specific program number in the OACIS. But multi programs can be saved in the local PC with same program number if program name is different.
- **Program Name:** Min string length is 1 and max string length is 32 bytes.
- **Date Time:** Time when the program saved. It is to be created by program. You do not need to input.

B. PROGRAM HOME POSITION

PROGRAM HOME POSITION		
AXIS NUMBER	POSITION	
AXIS #1	0	
AXIS #2	0	
AXIS #3	0	
AXIS #4	0	

- You can assign the program home position of each axis. The program home position is to be used for “Move to Program Home” function. To run a cycle. all axes need to be at home position or program home position.

C. GLOBAL VARIABLES and SYSTEM VARIABLES

GLOBAL VARIABLES and SYSTEM VARIABLES					IMPORT GV INFO	RESET FIELDBUS
PARAMETER	NAME	SAVE	Fieldbus In	Fieldbus ...		
Global Variable #1	Global Variable #1	<input type="checkbox"/>	0	0		
Global Variable #2	Global Variable #2	<input type="checkbox"/>	0	0		
Global Variable #3	Global Variable #3	<input type="checkbox"/>	0	0		
Global Variable #4	Global Variable #4	<input type="checkbox"/>	0	0		
Global Variable #5	Global Variable #5	<input type="checkbox"/>	0	0		
Global Variable #6	Global Variable #6	<input type="checkbox"/>	0	0		
Global Variable #7	Global Variable #7	<input type="checkbox"/>	0	0		
Global Variable #8	Global Variable #8	<input type="checkbox"/>	0	0		
Global Variable #9	Global Variable #9	<input type="checkbox"/>	0	0		
Global Variable #10	Global Variable #10	<input type="checkbox"/>	0	0		
Global Variable #11	Global Variable #11	<input type="checkbox"/>	0	0		
Global Variable #12	Global Variable #12	<input type="checkbox"/>	0	0		
Global Variable #13	Global Variable #13	<input type="checkbox"/>	0	0		
Global Variable #14	Global Variable #14	<input type="checkbox"/>	0	0		

- There are 100 global variables and 20 system variables. The variables are to be used at various functions like “Move to Position by Var”. Global Variables and System Variables are basically same except that the Global Variables are to be reset as zero by “Reset All Global Variables” but System Variables are not to be reset. (You can reset System Variable by using “Set Global Variable” function.)

- **Name:** You can assign specific name for each variable. The name should be unique.
- **Save:** You can set as “save” by checking the check box. Whenever OACIS complete a whole cycle, it saves all 120 variables with cycle number, program name and time information. And you can see only “save” checked variables on the “Result” and “DATA” tab of main screen.
- **Fieldbus In:** OACIS can receive mapped GV values from PLC by assigning the numbers from 1 to 45. You can assign Max 45 and number 0 means no mapping. You does not need to assign the numbers in order. But it is not allowable to reuse the same number. Additionally, simultaneous allocation of fieldbus in and out for a specified GV is prohibited.
- **Fieldbus Out:** It is the same as Fieldbus In except that OACIS can send mapped GV values to PLC. Here is an example of mapped Fieldbus In and Out below.

GLOBAL VARIABLES and SYSTEM VARIABLES			IMPORT GV INFO	RESET FIELDBUS
PARAMETER	NAME	SAVE	Fieldbus In	Fieldbus ...
Global Variable #1	Max Running Load	<input checked="" type="checkbox"/>	0	1
Global Variable #2	Min Running Load	<input checked="" type="checkbox"/>	0	2
Global Variable #3	End Load	<input checked="" type="checkbox"/>	0	3
Global Variable #4	End Position	<input checked="" type="checkbox"/>	0	4
Global Variable #5	Global Variable #5	<input type="checkbox"/>	0	0
Global Variable #6	Global Variable #6	<input type="checkbox"/>	0	0
Global Variable #7	Global Variable #7	<input type="checkbox"/>	0	0
Global Variable #8	Global Variable #8	<input type="checkbox"/>	0	0
Global Variable #9	Global Variable #9	<input type="checkbox"/>	0	0
Global Variable #10	Global Variable #10	<input type="checkbox"/>	0	0
Global Variable #11	Target Staking Position	<input checked="" type="checkbox"/>	1	0
Global Variable #12	Target Load	<input checked="" type="checkbox"/>	2	0
Global Variable #13	Global Variable #13	<input type="checkbox"/>	0	0
Global Variable #14	Global Variable #14	<input type="checkbox"/>	0	0

- **IMPORT GV INFO:** You can import GV information from another OACIS program.
- **RESET FIELDBUS:** You can set all the assigned values of fieldbus in & out as 0.

II. MOVE

A. Move to Position

CONFIGURATION	MOVE	SIGNAL	SEQUENCE
Move to Position	Move to Load	Move to DI	Move to Press
STEP Tag <input type="text" value="Move to Position"/>		INSERT	MODIFY
AXIS #1 (Enabled)			
Position [mm]	Speed [mm/s]	Acc. [mm/s ²]	
<input type="text" value="50.0000"/>	<input type="text" value="3.0000"/>	<input type="text" value="3.0000"/>	
Max Load Limit [kN]	Min Load Limit [kN]	Absolute	
<input type="text" value="1.0000"/>	<input type="text" value="-1.0000"/>		
AXIS #2 (Disabled)			
Position [mm]	Speed [mm/s]	Acc. [mm/s ²]	
<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	
Max Load Limit [kN]	Min Load Limit [kN]	Absolute	
<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>		

1. **Description:** Move the selected Axis to the specified position. Multi Axes can be selected.

2. **Parameters:**

- **Position:** Target Position to move / [mm] or [deg]
- **Speed:** [mm/s] or [deg/s]
- **Acceleration:** [mm/s²] or [deg/s²]
- **Max Load Limit / Min Load Limit:** If the load is higher than this limit, OACIS stops the operation and sends an error message / [kN] or [Nm].
- **Absolute or Relative:** You can use "Absolute" position or "Relative" position.
- **Step Tag:** The step tag to be used for DAQ or Sequence control. The Tag Name should be unique.

B. Move to Load

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	ME
Move to Position	Move to Load	Move to DI	Move to Press	Disable
STEP Tag <input type="text" value="Move to Load"/>		INSERT	MODIFY	Move to Program Home
AXIS #1 (Enabled)				
Target Load Ch.	Target Load [kN]	Holding Time [sec]		
Analog Input #1	<input type="text" value="2.0000"/>	<input type="text" value="0.0000"/>		
Speed [mm/s]	Acc. [mm/s ²]	Max Position Limit [mm]	Min Position Limit [mm]	
<input type="text" value="1.0000"/>	<input type="text" value="1.0000"/>	<input type="text" value="20.0000"/>	<input type="text" value="0.0000"/>	
AXIS #2 (Disabled)				
Target Load Ch.	Target Load [kN]	Holding Time [sec]		
Analog Input #1	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>		
Speed [mm/s]	Acc. [mm/s ²]	Max Position Limit [mm]	Min Position Limit [mm]	
<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	

1. **Description:** Move the selected Axis to the target load. Multi Axes can be selected.

2. Parameters:

- **Target Load Ch:** Analog Signal Input Channel for motion control. It is recommended to use default Analog Input Signal Channel.
- **Target Load:** Target Load to move / [kN] or [Nm]
- **Holding Time:** OACIS holds on the target load for the duration / [sec].
- **Speed:** [mm/s] or [deg/s]
- **Acceleration:** [mm/s²] or [deg/s²]
- **Max Position Limit / Min Position Limit:** If the OACIS fail to reach at the target load within the specified position limit, OACIS stop the operation and send an error message / [mm] or [deg].
- **Step Tag:** The step tag to be used for DAQ or Sequence control. The Tag Name should be unique.

C. Move to DI

CONFIGURATION		MOVE	SIGNAL	SEQUENCE	MEASUI
Move to Position	Move to Load	Move to DI	Move to Press	Disable	Move to Program Home
STEP Tag	Move to DI		INSERT	MODIFY	

MOVE TO DI			
Axis	Target DI	Direction	STOP CONDITION
Axis #1	Digital Input #1	Positive	OFF
Speed [mm/s]	Acc. [mm/s ²]		
1.0000	1.0000		
Max Position Limit [mm]	Min Position Limit [mm]	Max Load Limit	Min Load Limit
10.0000	0.0000	2.0000	0.0000

1. **Description:** Move the selected Axis until the target Digital Input signal turns on or off.

2. Parameters:

- **Axis:** Axis to move
- **Target DI:** Digital Input Channel to stop the motion
- **Direction:** The direction of motion. If you choose "Positive", the axis moves with positive direction to find stop condition / [Positive] or [Negative].
- **Stop Condition:** If you select [ON], the axis moves until the Digital Input signal turns on. If the signal is on when the motion is about to move, OACIS skip the step / [ON] or [OFF].
- **Speed:** [mm/s] or [deg/s]
- **Acceleration:** [mm/s²] or [deg/s²]
- **Max Position Limit / Min Position Limit:** If the OACIS fail to reach at the target load within the specified position limit, OACIS stop the operation and send an error message / [mm] or [deg].
- **Max Load Limit / Min Load Limit:** If the load is higher than this limit, OACIS stop the operation and send an error message / [kN] or [Nm].
- **Step Tag:** The step tag to be used for DAQ or Sequence control. The Tag Name should be unique.

FUNCTION DESCRIPTION

D. Move to Press

CONFIGURATION			MOVE	SIGNAL	SEQUENCE	MEASURE
Move to Position	Move to Load	Move to DI	Move to Press	Disable	Move to Program Home	Move to Position by
STEP Tag	Move to Press		INSERT	MODIFY		

MOVE TO PRESS

Axis
Axis #1

FIRST STROKE (FAST APPROACH)

Position [mm]	Speed [mm/s]	Acc. [mm/s ²]
10.0000	10.0000	10.0000

Max Load Limit [kN]	Min Load Limit [kN]
1.0000	-1.0000

SECOND STROKE (FINE PRESS)

Target Load Ch.	Target Load [kN]	Holding Time [ms]
Analog Input #1	3.0000	0.0000

Speed [mm/s]	Acc. [mm/s ²]	Max Position Limit [mm]	Min Position Limit [mm]
1.0000	1.0000	20.0000	0.0000

- Description:** It is special function for press operation combined with “Move to Position” and “Move to Load”. First Stroke is same as “Move to Position” and Second Stroke is same as “Move to Load”.

E. Disable

CONFIGURATION				MOVE	SIGNAL	SEQUENCE
Move to Position	Move to Load	Move to DI	Move to Press	Disable	Move to Program Home	
STEP Tag	Disable			INSERT	MODIFY	
AXIS	Axis #1					

- Description:** Disable the selected Axis until the next moving function happens. This function is useful to protect the Axis from unexpected external impact or interference. It is different from “Power Off”. Even you disable the axis, the OACIS is still monitoring the position. So when you enable the axis, you do not need to initialize the OACIS.
- Parameters:**
 - **Axis:** Axis to be disabled.
 - **Step Tag:** The step tag to be used for DAQ or Sequence control. The Tag Name should be unique.

F. Move to Program Home

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE
Move to Position	Move to Load	Move to DI	Move to Press	Disable
				Move to Program Home
				Move to Pos

STEP Tag

AXIS #1 (Enabled)

Speed [mm/s]	Acc. [mm/s ²]	Max Load Limit [kN]	Min Load Limit [kN]
<input type="text" value="30.0000"/>	<input type="text" value="30.0000"/>	<input type="text" value="1.0000"/>	<input type="text" value="-1.0000"/>

AXIS #2 (Disabled)

Speed [mm/s]	Acc. [mm/s ²]	Max Load Limit [kN]	Min Load Limit [kN]
<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>

- Description:** Move the selected Axis to the Program Home that is specified in the Program Configuration. Multi Axes can be selected. This function is useful to optimize axis travel. When you start Program, the Axes should be positioned at Home Position or Program Home Position. And you can save cycle time with reasonable Program Home Position.
- Parameters:**
 - **Speed:** [mm/s] or [deg/s]
 - **Acceleration:** [mm/s²] or [deg/s²]
 - **Max Load Limit / Min Load Limit:** If the load is higher than this limit, OACIS stop the operation and send an error message / [kN] or [Nm].
 - **Step Tag:** The step tag to be used for DAQ or Sequence control. The Tag Name should be unique.

G. Move to Position by Var

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Move to Position	Move to Load	Move to DI	Move to Press	Disable	Move to Program Home	Move to Position by Var

STEP Tag

AXIS #1 (Enabled)

Position [mm]	Speed [mm/s]	Acc. [mm/s ²]
<input type="text" value="001;Global Variable #1"/>	<input type="text" value="10.0000"/>	<input type="text" value="10.0000"/>
Max Load Limit [kN]	Min Load Limit [kN]	<input type="button" value="Absolute"/>
<input type="text" value="1.0000"/>	<input type="text" value="-1.0000"/>	

AXIS #2 (Disabled)

Position [mm]	Speed [mm/s]	Acc. [mm/s ²]
<input type="text" value=""/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>
Max Load Limit [kN]	Min Load Limit [kN]	<input type="button" value="Absolute"/>
<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	

- Description:** It is same as “Move to Position” except that the target position is to be assigned by selected global variable. Multi Axes can be selected. This function allows you to move the axis to various positions depending on process. The variable could be captured from analog signal or to be calculated to compensate proper position.

FUNCTION DESCRIPTION

H. Move to Position by Var #2

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Move to DI	Move to Press	Disable	Move to Program Home	Move to Position by Var	Move to Position by Var #2	
STEP Tag	Move to Position by Var #2	INSERT		MODIFY		
AXIS #1 (Enabled)						
Position 1 [mm]	Speed 1 [mm/s]	Acc. 1 [mm/s ²]		Absolute		
001;Global Variable #1	10.0000	10.0000				
Max Load Limit 1 [kN]	Min Load Limit 1 [kN]					
1.0000	-1.0000					
Position 2 [mm]	Speed 2 [mm/s]	Acc. 2 [mm/s ²]				
002;Global Variable #2	1.0000	0.0000				
Max Load Limit 2 [kN]	Min Load Limit 2 [kN]					
3.0000	0.0000					

- Description:** It is the same as “Move to Position by Var” function is applied twice except that the accelerating profile between the two “Move to Position by Var” is different from “Move to Position by Var #2”. Multi Axes can be selected. This function allows you to move the axis to various positions without any unnecessary accelerating or decelerating period. The variables could be captured from analog signal or to be calculated to compensate proper position.
- Parameters:**
 - **Position 1:** Target Position to move / [mm] or [deg]
 - **Speed 1:** [mm/s] or [deg/s]
 - **Acceleration 1:** [mm/s²] or [deg/s²]
 - **Max Load Limit 1 / Min Load Limit 1:** If the load is higher or lower than this limits, OACIS stop the operation and send an error message / [kN] or [Nm].
 - **Absolute or Relative:** You can use “Absolute” position or “Relative” position.
 - **Step Tag:** The step tag to be used for DAQ or Sequence control. The Tag Name should be unique.
 - The usage of No. 2 group like Position 2, Speed 2 and so on is the same as No. 1.

I. Dynamic Move to Position

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	MA
Disable	Move to Program Home	Move to Position by Var	Move to Position by Var #2	Dynamic Move to Position		Set As Home	
STEP Tag	Dynamic Move to Position	INSERT		MODIFY			
AXIS #1 (Enabled)							
Position [mm]	Speed [mm/s]	Acc. [mm/s ²]	Max Load Limit [kN]	Min Load Limit [kN]			
001;Global Variable #1	1.0000	1.0000	2.0000	0.0000			
Use	Range [mm]	Mode	"a" Value	"b" Value	Compensating Limit		
	5.0000 ~ 10.0000	Max	0.1000	0.2000	1.5000		
AXIS #2 (Disabled)							
Position [mm]	Speed	Acc. [mm/s ²]	Max Load Limit [kN]	Min Load Limit [kN]			
		0.0000	0.0000	0.0000			
Not Use	Range [mm]	Mode	"a" Value	"b" Value	Compensating Limit		
	0.0000 ~ 0.0000	Max	0.0000	0.0000	0.0000		

- Description:** It is same as “Move to Position” except that the OACIS is compensating target position depending on the running load. Multi Axis can be selected.

2. Parameters:


- **Position:** Target Position to move. Select a Global Variable as a Target Position / [mm] or [deg].
- **Speed:** [mm/s] or [deg/s]
- **Acceleration:** [mm/s²] or [deg/s²]
- **Max Load Limit / Min Load Limit:** If the load is higher than this limit, OACIS stop the operation and send an error message / [kN] or [Nm].
- **Use or Not Use:** Compensating function would be used or not used by this selection.
- **Range:** The range to get a compensating parameter.
- **Mode:** Mode to find Running Load / [Max], [Min], [Ave], [Slope1] and [Slope2]
 - Max: Capture maximum value in the range.
 - Min: Capture minimum value in the range.
 - Ave: Capture average value in the range.
 - Slope1: Calculate slope by using starting point and end point of the range.
 - Slope2: Calculate slope by using low point and high point in the range.
- **“a” and “b”:** Compensating value = “a” × “Running Load” + “b”
 - **So the actual final position = Position + Compensating Value**
- The running load is to be specified by “Mode” selection.
- **Compensating Limit:** If the compensating value is bigger than the limit, OACIS compensate by this limit.
 - For Example: If the calculated compensating value is 1.5, but the limit is 1.0, actual compensating value would be 1.0.
- **Step Tag:** The step tag to be used for DAQ or Sequence control. The Tag Name should be unique.

⚠ **Cautions**

- 1) In the dynamic control rage setting, the end position of dynamic control must be far from the position of start.



- 2) It is necessary to set the movement distance, speed, acceleration value of the command so that it becomes a trapezoidal trajectory with constant velocity section.



- 3) The dynamic control range must be set only within a constant velocity section (Between T1 and T2).
 - 4) The compensation limit is smaller than distance between the end position of dynamic range and T2 position.
- ✓ If you have any problem about this function, please do not hesitate to contact us.

FUNCTION

J. Set As Home

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Move to Program Home	Move to Position by Var	Move to Position by Var #2	Dynamic Move to Position	Set As Home		
STEP Tag	<input type="text" value="SetAs Home"/>	<input type="button" value="INSERT"/>	<input type="button" value="MODIFY"/>			
AXIS	<input type="text" value="1: Axis #1"/>					

- Description:** Set the current position of the selected Axis as Home Position. It is allowed only for homeless type Nut Runner. You can set the current position as Zero by using "Set AI or Position" function as well. But if you use the "Set AI or Position" function, new position will be valid in the cycle. So it is working differently from "Set AI or Position" function.
- Parameters:**
 - **Axis:** Axis to be set as Home
 - **Step Tag:** The step tag to be used for DAQ or Sequence control. The Tag Name should be unique.

K. Move to AI

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	MA
Move to Position by Var	Move to Position by Var #2	Dynamic Move to Position	Set As Home	Move to AI	Move to Load by Var		
STEP Tag	<input type="text" value="Move to AI"/>	<input type="button" value="INSERT"/>	<input type="button" value="MODIFY"/>				
AXIS #1 (Enabled)		Error and Stop with Position Limit		Error and Stop with Load Limit			
Target Value	Target AI Ch.	Direction	Speed [mm/s]	Acc. [mm/s^2]			
<input type="text" value="001;Global Variable #1"/>	<input type="text" value="Analog Input #1"/>	<input type="text" value="Positive"/>	<input type="text" value="1.0000"/>	<input type="text" value="1.0000"/>			
Signal Direction	Max Load Limit [kN]	Min Load Limit [kN]	Max Position Limit [mm]	Min Position Limit [mm]			
<input type="text" value="Increase"/>	<input type="text" value="3.0000"/>	<input type="text" value="0.0000"/>	<input type="text" value="10.0000"/>	<input type="text" value="0.0000"/>			
AXIS #2 (Disabled)							
Target Value	Target AI Ch.	Direction	Speed [mm/s]	Acc. [mm/s^2]			
<input type="text" value=""/>	<input type="text" value="Analog Input #1"/>	<input type="text" value="Positive"/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>			
Signal Direction	Max Load Limit [kN]	Min Load Limit [kN]	Max Position Limit [mm]	Min Position Limit [mm]			
<input type="text" value="Increase"/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>			

- Description:** Move the selected Axis to reach at the target value of the selected Analog Input Signal Channel. Multi Axes can be selected.
- Parameters:**
 - **Target Value:** Target value to move the Axis. The target value is to be assigned by selected global variable.
 - **Target AI Ch:** Analog Input Signal Channel for motion control. It is not recommended to use default Analog Input Signal Channel. (For default channel, please use "Move to Load" function).
 - **Direction:** The direction of motion. If you choose "Positive", the axis moves with positive direction to find stop condition / [Positive] or [Negative].
 - **Signal Direction:** In case that the starting value is lower than target value, "Increase" is to be selected. In the other case, "Decrease" is to be selected / [Increase] or [Decrease].
 - **Speed:** [mm/s] or [deg/s]
 - **Acceleration:** [mm/s^2] or [deg/s^2]
 - **Max Load Limit / Min Load Limit:** If the load is higher than this limit, OACIS stop the operation and send an error message / [kN] or [Nm].
 - **Max Position Limit / Min Position Limit:** If the OACIS fail to reach at the target load within the specified position limit, OACIS stop the operation and send an error message / [mm] or [deg].

- **Step Tag:** The step tag to be used for DAQ or Sequence control. The Tag Name should be unique.
- **“Move On to Next Step with Position Limit”**
 - **Move On to Next Step with Position Limit**
 - With this option, the cycle will move on to next step even if it fails to reach at the target value. If you want to move the selected channel to the target value **or** the position limit, this option would allow you to do that.
- **“Error and Stop with Position Limit”**
 - **Error and Stop with Position Limit**
 - With this option, it is working like “Move to Load”. It means, if the cycle fails to reach at the target value, it stops at the position limit with “Error” signal.
- **“Move On to Next Step with Load Limit”**
 - **Move On to Next Step with Load Limit**
 - With this option, the cycle will move on to next step even if it fails to reach at the target value like “Move On to Next Step with Position Limit”. If you want to move the selected channel to the target value **or** the load limit, this option would allow you to do that.
- **“Error and Stop with Load Limit”**
 - **Error and Stop with Load Limit**
 - With this option, it is working like “Move to Position”. It means, if the cycle fails to reach at the target value, it stops at the load limit with “Error” signal.
- **If you select these limit buttons in “Move to AI”, they are equally applied to all the selected Axis.**

L. Move to Load by Var

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS
Move to Position by Var #2	Dynamic Move to Position	Set As Home	Move to AI	Move to Load by Var	Move to Load by Var
STEP Tag <input type="text" value="Move to Load by Var"/>		INSERT		MODIFY	
AXIS #1 (Enabled)		Error and Stop with Position Limit			
Target Load Ch.	Target Load [kN]	Holding Time [sec]			
Analog Input #1	001;Global Variable #1	0.0000			
Speed [mm/s]	Acc. [mm/s ²]	Max Position Limit [mm]	Min Position Limit [mm]		
1.0000	1.0000	20.0000	0.0000		
AXIS #2 (Disabled)					
Target Load Ch.	Target Load [kN]	Holding Time [sec]			
Analog Input #1		0.0000			
SPEED [mm/s]	Acc. [mm/s ²]	Max Position Limit [mm]	Min Position Limit [mm]		
0.0000	0.0000	0.0000	0.0000		

1. Description: It is same as “Move to Load” except for followings.

- Target Load is to be assigned by selected global variable.
- **“Move On to Next Step with Position Limit”**
 - **Move On to Next Step with Position Limit**
 - With this option, the cycle will move on to next step even if it fails to reach at the target load. If you want to move the selected Axis to the target load **or** the position limit, this option would allow you to do that. For sure, the Target Load has priority.
- **“Error and Stop with Position Limit”**

FUNCTION DESCRIPTION

Error and Stop with Position Limit

-
- With this option, it is working like “Move to Load”. It means, if the cycle fails to reach at the target load, it stop at the position limit with “Error” signal. (with 602, 702, 802 or 902 error code).

M. Move to Bottom

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	MA
Move to Position by Var #2	Dynamic Move to Position	Set As Home	Move to AI	Move to Load by Var	Move to Bottom	Move	
STEP Tag	Move to Bottom	INSERT	MODIFY				
AXIS #1 (Enabled)		Error and Stop with Position Limit & Load Limit					
Target Load Ch.	Target Load [kN]	Holding Time [sec]	Speed [mm/s]	Acc. [mm/s^2]	Max Pos. Limit [mm]		
Analog Input #1	3.0000	0.0000	1.0000	1.0000	10.0000		
GV To Save Failure Mode	Delta X [mm]	Delta Y [kN]	Delta T [ms]	Bottoming Range [mm]	Min Pos. Limit [mm]		
001;Global Variable #1	0.0100	0.0500	1	8.0000 ~ 9.0000	0.0000		
AXIS #2 (Disabled)							
Target Load Ch.	Target Load [kN]	Holding Time [sec]	Speed [mm/s]	Acc. [mm/s^2]	Max Pos. Limit [mm]		
Analog Input #1	0.0000	0.0000	0.0000	0.0000	0.0000		
GV To Save Failure Mode	Delta X [mm]	Delta Y [kN]	Delta T [ms]	Bottoming Range [mm]	Min Pos. Limit [mm]		
	0.0000	0.0000	0	0.0000 ~ 0.0000	0.0000		

1. **Description:** It moves the selected Axis to the specified bottoming condition.

2. **Parameters:**

- **Target Load Ch:** Analog Signal Input Channel for motion control. It is recommended to use default Analog Input Signal Channel.
- **Target Load:** Target Load to move. If it finds bottoming condition, it stops at the position before reaching at the Target Load / [kN] or [Nm].
- **Holding Time:** OACIS holds on the bottoming position for the duration / [sec].
- **Speed:** [mm/s] or [deg/s]
- **Acceleration:** [mm/s^2] or [deg/s^2]
- **Max Position Limit / Min Position Limit:** Position limits for the step.
- **GV to Save Failure Mode:** It saves detailed information to the selected global variable as below per the failure mode.
 - **1:** Ok. OACIS found the bottoming condition before reaching at the target load within position limits.
 - **2:** OACIS failed to find bottoming condition and reached at the target load within position limits.
 - **3:** OACIS failed not only to find bottoming condition but also reach at the target load within position limits.
- **Delta X [mm or deg] / Delta Y [kN or Nm] / Delta T [ms]**
 - Bottoming Condition is to be defined by three parameters, Delta X, Delta Y and Delta T. If the actual “ $\delta y / \delta x$ ” is greater than the specified “Delta Y / Delta X” in longer time span than the specified “Delta T”, the OACIS stops the Axis with recognition of bottoming.
- **Bottoming Range:** OACIS finds “Bottoming Condition” only in this range. It helps you not to stop the Axis in the unexpected area with unexpected load spike / [mm] or [deg].
- **Move On to Next Step with Position Limit Load Limit:** You can move on to next step even though the cycle failed to find bottoming condition before reaching at the target load or within the position limits. Otherwise, the cycle will stop at the end of the step with “Error” signal. (Refer to the “Move to Load by Var”)

3. **Example:**



CONFIGURATION **MOVE** SIGNAL SEQUENCE MEASURE ANALYSIS GAGE MATH

Move to Position by Var Dynamic Move to Position Set As Home Move to AI Move to Load by Var **Move to Bottom**

STEP Tag **INSERT** **MODIFY**

AXIS #1 (Enabled) Error and Stop with Position Limit & Load Limit

Target Load Ch.	Target Load [kN]	Holding Time [sec]	Speed [mm/s]	Acc. [mm/s ²]	Max Position Limit [mm]
Analog Input #1	15.0000	0.0000	2.0000	5.0000	240.0000

GV To Save Failure Mode	Delta X [mm]	Delta Y [kN]	Delta T [ms]	Bottoming Range [mm]	Min Position Limit [mm]
001;Global Variable #1	1.0000	3.0000	100	220.0000 ~ 240.0000	0.0000

Here you set the Bottoming Condition = 3/1 (kN/mm) with longer than 100ms time span. And you see the above curve that shows how OACIS stops the Axis at the Bottoming Condition.

N. Move to Load by Var #2

Dynamic Move to Position Set As Home Move to AI Move to Load by Var Move to Bottom **Move to Load by Var #2** Move

STEP Tag **INSERT** **MODIFY**

AXIS #1 (Enabled) Error and Stop with Position Limit

Target Load Ch.	Max Position Limit [mm]	Min Position Limit [mm]	Holding Time [sec]
Analog Input #1	20.0000	0.0000	0.0000
Target Load #1 [kN]			
001;Global Variable #1			
Speed #1 [mm/s]			
5.0000			5.0000
Acc. #1 [mm/s ²]			
5.0000			
Target Load #2 [kN]			
002;Global Variable #2			
Speed #2 [mm/s]			
1.0000			1.0000
Acc. #2 [mm/s ²]			
1.0000			

AXIS #2 (Disabled)

Target Load Ch.	Max Position Limit [mm]	Min Position Limit [mm]	Holding Time [sec]
Analog Input #1	0.0000	0.0000	0.0000
Target Load #1 [kN]			
SPEED #1 [mm/s]			
0.0000			0.0000
Acc. #1 [mm/s ²]			
0.0000			
Target Load #2 [kN]			
SPEED #2 [mm/s]			
0.0000			0.0000
Acc. #2 [mm/s ²]			
0.0000			

- Description:** It is working like “Move to Load” or “Move to Load by Var”. But you can specify Target Load #1 and Target Load #2 respectively. Each Target Load has its own Speed and Acceleration. By specifying two Target Loads, you can get more accurate result. If you use fast speed for “Move to Load” function, it is hard to prevent “Over Shoot”. But low speed requires longer cycle time. So, you can move to Target


FUNCTION DESCRIPTION

Load #1 fast and move to Target Load #2 slowly to reach at the final Target Load without “Over Shoot”.

2. Parameters:

- **Target Load Ch:** Analog Signal Input Channel for motion control. It is recommended to use default Analog Input Signal Channel.
- **Target Load #1:** First Target Load to reach / [kN] or [Nm]
- **Speed #1:** Speed to reach at Target Load #1 / [mm/s] or [deg/s]
- **Acceleration #1 :** Acceleration to reach at Target Load #1 / [mm/s²] or [deg/s²]
- **Target Load #2:** Final Target Load to reach / [kN] or [Nm]
- **Speed #2:** Speed to reach at Target Load #2 / [mm/s] or [deg/s]
- **Acceleration #2 :** Acceleration to reach at Target Load #2 / [mm/s²] or [deg/s²]
- **Holding Time:** OACIS holds on the Target Load #2 for the duration / [sec].
- **Max Position Limit / Min Position Limit:** If the OACIS fail to reach at the target load within the specified position limit, OACIS stop the operation / [mm] or [deg].
- **“Move On to Next Step with Position Limit”**
 - **Move On to Next Step with Position Limit**
 - With this option, the cycle will move on to next step even if it fails to reach at the target load. If you want to move the selected Axis to the target load or the position limit, this option would allow you to do that. For sure, the Target Load has priority.
- **“Error and Stop with Position Limit”**
 - **Error and Stop with Position Limit**
 - With this option, it is working like “Move to Load”. It means, if the cycle fails to reach at the target load, it stop at the position limit with “Error” signal. (with 602, 702, 802 or 902 error code).

3. Example:



If your Target Load is 8kN, you can set the parameters as below,

- Target Load #1: 6 kN
- Speed #1: 5 mm/s
- Acc. #1: 10 mm/s²
- Target Load #2: 8 kN
- Speed #2: 0.5 mm/s
- Acc. #2: 1 mm/s²

O. Move to Position with Limited Load

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GA
Move to AI	Move to Load by Var	Move to Bottom	Move to Load by Var #2	Move to Position with Limited Load		
STEP Tag <input type="text" value="Move to Position with Limited Load"/>		INSERT	MODIFY			
AXIS #1 (Enabled)		Error and Stop with Time Limit				
Position [mm] <input type="text" value="001;Global Variable #1"/>		Speed [mm/s] <input type="text" value="3.0000"/>	Acc. [mm/s^2] <input type="text" value="3.0000"/>			
Max Limited Load [kN] <input type="text" value="2.0000"/>	Min Limited Load [kN] <input type="text" value="0.0000"/>	TimeLimit [sec] <input type="text" value="1.0000"/>	Absolute			

- Description:** It is working like “Move to Position” or “Move to Position by Var”. But you can specify “Limited Load” and “Time Limit”. “Limited Load” is different from “Load Limit”. When the Axis meets the “Limited Load” before it reaches the target Position, OACIS is to hold the Axis at the “Limited Load”. And if the load decreases (or increases depending on the “Max Limited Load” or “Min Limited Load”), OACIS starts to move the Axis to the target Position. If the holding time at the “Limited Load” is longer than the “Time Limit”, OACIS shows Error or move on to the next step depending on “Error and Stop with Time Limit” option.

Note: The function can be used only if the moving direction is the same as the load direction. When the Axis moves forwards, the load should be increased.

2. Parameters:

- **Position:** Target Position / [mm] or [deg].
- **Speed:** Speed to reach at the Position / [mm/s] or [deg/s]
- **Acceleration:** Acceleration to reach at the Position / [mm/s^2] or [deg/s^2]
- **Time Limit:** If OACIS meets the “Limited Load” before the Position, OACIS is keeping the load until the Load decrease (or increase) during the “Time Limit” / [sec].
- **Max Limited Load / Min Limited Load:** The Axis moves between these Limited Loads / [kN] or [Nm]. When the Axis is moving forwards, OACIS will hold the Axis at the “Max Limited Load” during the Time Limit. On the contrary, if the Axis is moving backwards, OACIS will hold at “Min Limited Load”
- **Absolute or Relative:** You can use “Absolute” position or “Relative” position.
- **“Move On to Next Step with Time Limit”**
 - **Move On to Next Step with Time Limit**
 - With this option, the cycle will move on to next step even if it fails to reach at the target position in the Time Limit.
- **“Error and Stop with Position Limit”**
 - **Error and Stop with Time Limit**
 - With this option, OACIS stops and shows Error at the step when it fails to reach at the target position with “Time Limit”.

FUNCTION DESCRIPTION

P. Start Hold Load / End Hold Load

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	MA
Move to Load by Var	Move to Bottom	Move to Load by Var #2	Move to Position with Limited Load	Start Hold Load	End Hold L		
STEP Tag	Start Hold Load	INSERT	MODIFY				
AXIS	Axis #1						

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	G
Move to Bottom	Move to Load by Var #2	Move to Position with Limited Load	Start Hold Load	End Hold Load		
STEP Tag	End Hold Load	INSERT	MODIFY			
AXIS	Axis #1					

- Description:** OACIS is normally controlling position except for “load control function” like “Move to Load”. But if you want to keep specific load while OACIS is doing non-motional function such as “Analysis” or “Sequence”, you can use these functions.
- Hold Load Start Condition:** All move functions keep basically “Hold Position” mode after finishing the functions. But “Hold Load” mode starts exceptionally under the condition below.
 - When a “Start Hold Load” function is executed and then one of load-related functions gets normally terminated without any errors, OACIS is controlling “load” instead of “position” according to parameter conditions of the load function such as target load, speed, Acc. and error limits.
 - Load-related functions include Move to Load, Move to Press, Move to Load by Var, Move to Bottom and Move to Load by Var #2.
- Hold Load End Conditions:** One of followings will end “Hold Load” condition. (It means it will be changed to position control mode).
 - End Hold Load
 - Position control functions (Move to Position, Move to Position by Var, ...)
 - Move to Bottom: If OACIS complete it successfully (find bottoming condition), it will keep the hold load, otherwise, it will change to position control mode.
 - Abnormal Condition: OACIS also enters into “Hold Position” mode when it returns to normal from abnormal condition such as E-stop, Stop-Resume, Reset and Errors
- Precautions:**

The “Hold Load” mode is not a normal condition and can cause severe problems or a dangerous situation. So you should pay special attention and need to be careful when it comes to the “Hold Load” mode

Q. Deactivate

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Move to Load by Var #2	Move to Position with Limited Load	Start Hold Load	End Hold Load	Deactivate		
STEP Tag	Deactivate	INSERT	MODIFY			
AXIS	Axis #1					

- Description:** Deactivate the selected Axis until the next moving function happens. This function is useful both to protect the Axis from unexpected external interference and to reduce the noise from Servo Motors. The difference between “Disable” and “Deactivate” is to get the servo enable signal On or Off. Disable

function sets the output as Zero so that the servo is still enabled. However, Deactivate function sets the servo enable as off. It is also different from “Power Off”. Even you deactivate the axis, the OACIS is still monitoring the position. So when you enable the axis, you do not need to initialize the OACIS.

Note: Deactivate function sets the servo enable as Off and the brake as deactivated (brake LED On). Therefore, you should be cautious about using this function especially when the tooling weighs too high.

2. Parameters:

- **Axis:** Axis to be deactivated.
- **Step Tag:** The step tag to be used for DAQ or Sequence control. The Tag Name should be unique.

R. Move to Load by Var #3

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	MATH
Move to Position with Limited Load	Start Hold Load	End Hold Load	Deactivate	Move to Load by Var #3			
STEP Tag: Move to Load by Var #3		INSERT		MODIFY			
AXIS #1 (Enabled)		Error and Stop with Position Limit					
Target Load Ch.	Target Load [kN]		Holding Time [sec]				
Analog Input #1			0.0000				
Speed [mm/s]	Acc. [mm/s^2]	Max Position Limit [mm]		Min Position Limit [mm]			
1.0000	1.0000	100.0000		0.0000			
Target Load Tol.[kN]	Max Delta Dist. [mm]						
0.1000	50.0000						

1. **Description:** It is working like “Move to Load” or “Move to Load by Var”. But you can specify the exit condition in more detail with two options which are “Target Load Tol.” and “Max Delta Dist.”. When one of two turns out to be satisfied, OACIS will terminate this function.

2. Parameters:

- **Target Load Ch:** Analog Signal Input Channel for motion control. It is recommended to use default Analog Input Signal Channel.
- **Target Load:** Target Load to reach / [kN] or [Nm]
- **Speed:** Speed to reach at Target Load / [mm/s] or [deg/s]
- **Acceleration:** Acceleration to reach at Target Load / [mm/s^2] or [deg/s^2]
- **Holding Time:** OACIS holds on the Target Load for the duration / [sec].
- **Max Position Limit / Min Position Limit:** If the OACIS fail to reach at the target load within the specified position limit, OACIS stop the operation / [mm] or [deg].
- **“Move On to Next Step with Position Limit”**
 - **Move On to Next Step with Position Limit**
 - With this option, the cycle will move on to next step even if it fails to reach at the target load. If you want to move the selected Axis to the target load or the position limit, this option would allow you to do that. For sure, the Target Load has priority.
- **“Error and Stop with Position Limit”**
 - **Error and Stop with Position Limit**
 - With this option, it is working like “Move to Load”. It means, if the cycle fails to reach at the target load, it stop at the position limit with “Error” signal. (with 602, 702, 802 or 902 error code).
- **Target Load Tol.:** When the OACIS reaches the range within “Target Load +/- Target Load Tolerance”, it terminates this function / [kN] or [Nm]. Target Load Tolerance is an absolute value.
- **Max Delta Dist.:** If OACIS arrives at the +/- relative position of Max Delta Distance from the get-go, it exits the function / [mm] or [deg]. Max Delta Distance is an absolute value.

FUNCTION DESCRIPTION

III. SIGNAL

A. Set AI or Position

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANAL
Set AI or Position	Set DO	Reset All DO	Set Status Binary	Set Signal Filter	Set DO by Signal
STEP Tag	Set AI or Position			INSERT	MODIFY
SIGNAL INPUT Ch.		SET VALUE			
Analog Input #1		0.0000			

- Description:** Set the selected analog signal channel as the specific value. New setting value is valid till the cycle ends. After the cycle ends, OACIS sets the channel as absolute value.
 - Note:** "Move to Program Home" function does not use offset value.
- Parameters:**
 - Analog Input Ch.:** Analog Input Channel to be set as new value. One of Analog Input #1 ~ #12, RS422 Ch #1 ~ #4, Axis Position #1 ~ #4 or Encoder Input Ch #1 ~ #8.
 - Set Value:** New value to be used for the selected Analog Input Channel.
 - Step Tag:**

B. Set DO

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANAL
Set AI or Position	Set DO	Reset All DO	Set Status Binary	Set Signal Filter	Set DO by Signal
STEP Tag	Set DO			INSERT	MODIFY
DIGITAL OUTPUT Ch.		SET VALUE			
Digital Output #1		OFF			

- Description:** Set the selected Digital Output channel as On or Off.
- Parameters:**
 - Digital Output Ch.:** Digital Output Channel to be set. Programmable DO #1 ~ #14.
 - Set Value:** [On] or [Off].
 - Step Tag:**

C. Reset All DO

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANAL
Set AI or Position	Set DO	Reset All DO	Set Status Binary	Set Signal Filter	Set DO by Signal
STEP Tag	ResetAll DO			INSERT	MODIFY

- Description:** Set the all Programmable Digital Output channels as Off. Normally it is used at the beginning of program to reset signal.
- Parameters:**
 - Step Tag:**

D. Set Status Binary

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANAL
Set AI or Position	Set DO	Reset All DO	Set Status Binary	Set Signal Filter	Set DO by Signal
STEP Tag	Set Status Binary		INSERT	MODIFY	
SET VALUE					
0					

- Description:** Set the Status Binary as specific value. It would be used to show part status (good or bad) or failure mode to external device like PLC. If you set the value as 5, Status Bin #1 and #3 would be [On] Bin #2 and #4 would be [Off].
 - Value = Bin#1 x 1 + Bin#2 x 2 + Bin#3 x 4 + Bin#4 x 8
- Parameters:**
 - Set Value:** 0 ~ 15.
 - 0: Set all [Off] / 15: Set all [On].
 - Step Tag:**

E. Set Signal Filter

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANAL
Set AI or Position	Set DO	Reset All DO	Set Status Binary	Set Signal Filter	Set DO by Signal
STEP Tag	Set Signal Filter		INSERT	MODIFY	
ANALOG INPUT Ch.		FILTERING RATE			
Analog Input #1		0			

- Description:** Set the selected Analog Input Channel digital filter. New filtering setting would be valid until cycle ends. (After cycle ends, OACIS sets the filter as System Configuration value). It is working as digital low pass filter. The higher value would make the more stable value and the lower value would make the more sensitive value.
- Parameters:**
 - Filtering Rate:** 0 ~ .
 - Step Tag:**

FUNCTION DESCRIPTION

F. Set DO by Signal

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANAL
Set AI or Position	Set DO	Reset All DO	Set Status Binary	Set Signal Filter	Set DO by Signal
STEP Tag		Set DO by Signal		INSERT	MODIFY
DIGITAL OUTPUT Ch.		SET VALUE			
Digital Output #1		OFF			
ANALOG INPUT Ch.		TARGET VALUE			
Analog Input #1		0.0000			
TARGET STEP					
001-Move to Position by Var					

- Description:** Set the selected Digital Output channel as On or Off when the selected Analog Input Channel reach at the Target Value while the selected Target Step is running.
- Parameters:**
 - **Digital Output Ch.:** Digital Output Channel to be set. Programmable DO #1 ~ #14.
 - **Set Value:** [On] or [Off].
 - **Analog Input Ch.:** Analog Input Channel to be used as setting condition.
 - **Target Value:** Target Value to set the selected Analog Input channel.
 - **Target step:** Target Step to set the Selected DO channel as On or Off. It should be located before the selected Target Step.
 - **Step Tag:**

G. Set As Abs Value

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Set AI or Position	Set DO	Reset All DO	Set Status Binary	Set Signal Filter	Set DO by Signal	Set As Abs Value
STEP Tag		SetAs Abs Value		INSERT	MODIFY	
SIGNAL INPUT Ch.		SET VALUE				
Encoder Input #1 (TTL)		0.0000				

- Description:** Set the selected Signal Input channel as the specified set value. The Set Value will be a new absolute value. It differs from "Set AI or Position" function. "Set AI or Position" is valid only in the cycle. But it changes system configuration. OACIS will have new absolute value.
 - **Note:** You should be careful to use this function especially for the Signal Input Channels with current or voltage type signal. In some cases, the system will have accumulative errors.
- Parameters:**
 - **Signal Input Ch.:** Signal Input Channel to be set with new absolute value
 - **Set Value:** New absolute value to be used for the selected Signal Input Channel.
 - **Step Tag:**

H. Set AI or Position by Var

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Set DO	Reset All DO	Set Status Binary	Set Signal Filter	Set DO by Signal	Set As Abs Value	Set AI or Position by Var

STEP Tag

SIGNAL INPUT Ch.

GLOBAL VARIABLE to SET VALUE

- Description:** This function is same as “Set AI or Position” except for that you can specify the setting value by selecting a global variable.

I. Set As Abs Value by Var

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Set Status Binary	Set Signal Filter	Set DO by Signal	Set As Abs Value	Set AI or Position by Var	Set As Abs Value by Var	

STEP Tag

SIGNAL INPUT Ch.

GLOBAL VARIABLE to SET VALUE

- Description:** This function is same as “Set As Abs Value” except for that you can specify the setting value by selecting a global variable.

J. Send Out Data

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Set Signal Filter	Set DO by Signal	Set As Abs Value	Set AI or Position by Var	Set As Abs Value by Var	Send Out Data	

STEP Tag

RS232 Com Port to Send Out Data (Need to be configured as "Data Out" in Configuration)

GLOBAL VARIABLE to be Sent Out (From)

GLOBAL VARIABLE to be Sent Out (To)

INCLUDE SERIAL No INCLUDE STATUS BIN INCLUDE TIME

- Description:** You can send out the selected Global Variable data through the selected RS232 communication port.

- Note:** The selected RS232 Com Port needs to be configured as “Data Out” mode not “Scan In” mode. See the manual of “How to configure” for more details.

FUNCTION DESCRIPTION

2. Parameters:

- **RS232 Com Port to Send Out Data:** The Com Port is to be used to send out data
- **GLOBAL VARIABLE to be Sent Out (From) and (To):** If you select Global Variable #1 as “From” and Global Variable #3 as “To”, OACIS will send out Global Variable #1 through Global Variable #3.
- **INCLUDE SERIAL No / STATUS BIN / TIME:** When you send out data, you can attached a few optional information like “Serial No”, “Status Bin” and “Time”.
 - **Note:** All the information to be sent will be the value at that step. So, you may need to consider where this step needs to be inserted to send out proper data.
- **Step Tag:**

3. Send Out Data Format: “GV;FA;GV1;GV2;GV3...;SerialNo;StatusBin;Time;” + CR

- GV;FA -> Header
- CR -> End Terminator

4. Example:

- **Assumptions:**
 - GLOBAL VARIABLE to be Sent Out (From): Global Variable #1
 - GLOBAL VARIABLE to be Sent Out (To): Global Variable #3
 - All Options selected as “YES”
- **OACIS sends out data as below:**
 - “GV;FA;+0000.0001;+0000.0002;+0000.0003;123456789;15;130328010101;” + CR
- **If No Option selected:**
 - “GV;FA;+0000.0001;+0000.0002;+0000.0003;” + CR

IV. SEQUENCE

A. Jump Tag

CONFIGURATION	MOVE	SIGNAL	SEQUENCE
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition
			Jump by Multi Conditions
STEP Tag	Jump Tag		<input type="button" value="INSERT"/> <input type="button" value="MODIFY"/>

- Description:** The step has only tag without any function. It is to be used for target step to jump.
- Parameters:**
 - Step Tag:**

B. Jump to Step

CONFIGURATION	MOVE	SIGNAL	SEQUENCE
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition
			Jump by Multi Conditions
STEP Tag	Jump to Step		<input type="button" value="INSERT"/> <input type="button" value="MODIFY"/>
TARGET STEP <input type="text" value=""/> <ul style="list-style-type: none"> 001-Move to Position 002-Move to Load 003-Move to DI 004-Program End 			

- Description:** Jump to the selected step
 - Note:** If this function is used among “Loop” – “Loop End” function, a step to jump should surely be included among “Loop” function.
- Parameters:**
 - Target Step:** Step to jump.
 - Step Tag:**

C. Jump to Step by DI

CONFIGURATION	MOVE	SIGNAL	SEQUENCE
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition
			Jump by Multi Conditions
STEP Tag	Jump to Step by DI		<input type="button" value="INSERT"/> <input type="button" value="MODIFY"/>
DIGITAL INPUT Ch. <input type="text" value="Digital Input #1"/>			
STEP TO JUMP (Case ON) <input type="text" value="003-Move to DI"/>			
STEP TO JUMP (Case Off) <input type="text" value="002-Move to Load"/>			

1. **Description:** Jump to the selected step by the condition of the selected Digital Input signal.
 - **Note:** If this function is used among “Loop” – “Loop End” function, a step to jump should surely be included among “Loop” function.
2. **Parameters:**
 - **Digital Input Ch.:** Digital Input Signal Channel
 - **Step to Jump (Case On):** The target step to jump in the case of the selected DI On.
 - **Step to Jump (Case Off):** The target step to jump in the case of the selected DI Off.
 - **Step Tag:**

D. Jump by Condition

CONFIGURATION	MOVE	SIGNAL	SEQUENCE
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition

STEP Tag INSERT MODIFY

GLOBAL VARIABLE TO COMPARE		VALUE TO COMPARE
<input type="text" value="001;Global Variable #1"/>	▼	<input type="text" value="0.0000"/> ?
CASE: TRUE		
STEP TO JUMP		
<input type="text" value="000-Next"/>		
CASE: FALSE		
STEP TO JUMP		
<input type="text" value="004-Program End"/>		

1. **Description:** Jump to the selected step by the condition of comparison operators.
2. **Parameters:**
 - **Global Variable to Compare:** Object to compare.
 - **Comparison Operators:** You can select one of them (>, >=, =, <=, <).
 - **Value to Compare:** Real number to compare.
 - **Step to Jump (Case True):** The target step to jump if the condition is true. If you select “Next”, it will go to the step next to “Jump by Condition”.
 - **Step to Jump (Case False):** The target step to jump if the condition is false.
 - **Step Tag:**

3. Example

- If GV #1 is greater than 0 at step 3, it moves to **step 4** (Move to Position by Var). But if GV #1 is less than or equals to 0 at Step 3, it jumps to **step 5** (Move to Load).

DELETE	COPY	PASTE	CUT	CONFIGURATION	MOVE	SIGNAL	SEQUENCE
				Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition

STEP Tag INSERT MODIFY

GLOBAL VARIABLE TO COMPARE		VALUE TO COMPARE
<input type="text" value="001;Global Variable #1"/>	>	<input type="text" value="0.0000"/> ?
CASE: TRUE		
STEP TO JUMP		
<input type="text" value="004-Move to Position by Var"/>		
CASE: FALSE		
STEP TO JUMP		
<input type="text" value="005-Move to Load"/>		

STEP	FUNCTION	TAG
001	Move to Position	Move to PrePosition
002	DAQ	DAQ
> 003	Jump by Condition	Jump by Condition
004	Move to Position by...	Move to Position by Var
005	Move to Load	Move to Load
006	Jump Tag	Pass
007	Jump Tag	High Reject
008	Jump Tag	Low Reject
009	Program End	Program End

E. Jump by Condition #2

CONFIGURATION	MOVE	SIGNAL	SEQUENCE
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition
Jump by Condition #2			
STEP Tag	Jump by Condition #2		<input type="button" value="INSERT"/> <input type="button" value="MODIFY"/>
GV #1 TO COMPARE	<div style="display: flex; align-items: center;"> <div style="border: 1px solid gray; padding: 2px;">002;Global Variable #2</div> <div style="margin: 0 5px;"> <input type="button" value=">"/> <input type="button" value=">="/> <input type="button" value="="/> <input type="button" value="<="/> <input type="button" value="<"/> </div> <div style="border: 1px solid gray; padding: 2px;">001;Global Variable #1</div> <div style="margin-left: 5px;">?</div> </div>		
CASE: TRUE			
STEP TO JUMP	004-____PASS		
CASE: FALSE			
STEP TO JUMP	007-____FAIL		

- Description:** It is same as “Jump by Condition” except that objects to compare are all Global Variables.
- Parameters:**
 - **GV #1 To Compare:** Object to compare.
 - **Comparison Operators:** You can select one of them (>, >=, =, <=, <).
 - **GV #2 To Compare:** Another object to be compared.
 - **Step to Jump (Case True):** The target step to jump if the condition is true. If you select “Next”, it will go to the step next to “Jump by Condition”.
 - **Step to Jump (Case False):** The target step to jump if the condition is false.
 - **Step Tag:**

F. Jump by Multi Conditions

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition	Jump by Multi Conditions
Jump by Multi Conditions				
STEP Tag	Jump by Multi Conditions		<input type="button" value="INSERT"/> <input type="button" value="MODIFY"/>	
Global Variable to compare				
001;Global Variable #1				
IF ...	>	3.0000	Jump To ...	004-Program End
Else IF ...	<=	1.0000	Jump To ...	002-Move to Load
Else IF ...	<=	3.0000	Jump To ...	003-Move to DI
Else IF ...	>	0.0000	Jump To ...	000-Next
Else IF ...	>	0.0000	Jump To ...	000-Next
Else IF ...	>	0.0000	Jump To ...	000-Next
Else IF ...	>	0.0000	Jump To ...	000-Next
Else IF ...	>	0.0000	Jump To ...	000-Next
Else IF ...	>	0.0000	Jump To ...	000-Next
Else IF ...	>	0.0000	Jump To ...	000-Next
Else ...			Jump To ...	000-Next

- Description:** Jump to the selected step of the condition that meets amongst multi conditions. This function moves downward from the “IF...” condition and terminates at the satisfied step.

FUNCTION DESCRIPTION

2. Parameters:

- Global Variable to Compare: Object to compare.
- Comparison Operators: You can select one of them (>, >=, =, <=, <).
- Value to Compare: Real number to compare.
- Jump to...: The target step to jump if the condition is true. If you select "Next", it will go to the step next to "Jump by Multi Conditions". The maximum number of jump to...steps that you can assign is 11.
- **Step Tag:**

3. Example: See the next page.

- When you want to make a program including over three conditional statements as below, this function is very useful. You can assign the condition up to 11.
 - If GV #1 is less than 0 at Step 6, it jumps to step 7 (Case #1).
 - If GV #1 is less than or equals to 3 at Step 6, it jumps to step 10 (Case #2).
 - If GV #1 is greater than 3 at Step 6, it jumps to step 13 (Case #3).

DELETE	COPY	PASTE	CUT
STEP	FUNCTION	TAG	
001	Jump Tag	===== MOVE	
002	Move to Position	Move to PrePosition	
003	DAQ	DAQ	
004	Move to Position by...	Move to Position by Var	
005	Move to Load	Move to Load	
> 006	Jump by Multi Condi...	Jump by Multi Conditions	
007	Jump Tag	CASE #1	
008	Math1	Math1	
009	Jump to Step	Jump to Step	
010	Jump Tag	CASE #2	
011	Math2	Math2	
012	Jump to Step	Jump to Step1	
013	Jump Tag	CASE #3	
014	Math3	Math3	
015	Jump Tag	===== GAGING	
016	Jump Tag	Pass	
017	Jump Tag	High Reject	
018	Jump Tag	Low Reject	
019	Jump Tag	===== PROGRAM EN	
020	Program End	Program End	

CONFIGURATION	MOVE	SIGNAL	SEQUENCE
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition
			Jump by Multi Conditions
STEP Tag	Jump by Multi Conditions		INSERT MODIFY
Global Variable to compare			
001;Global Variable #1			
IF ...	<	0.0000	Jump To ... 007-CASE #1
Else IF ...	<=	3.0000	Jump To ... 010-CASE #2
Else IF ...	>	3.0000	Jump To ... 013-CASE #3
Else IF ...	>	0.0000	Jump To ... 000-Next
Else IF ...	>	0.0000	Jump To ... 000-Next
Else IF ...	>	0.0000	Jump To ... 000-Next
Else IF ...	>	0.0000	Jump To ... 000-Next
Else IF ...	>	0.0000	Jump To ... 000-Next
Else IF ...	>	0.0000	Jump To ... 000-Next
Else IF ...	>	0.0000	Jump To ... 000-Next
Else IF ...	>	0.0000	Jump To ... 000-Next
Else ...			Jump To ... 020-Program End

FUNCTION DESCRIPTION

G. Loop Start

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASUREMENT
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition	Jump by Multi Conditions
				Loop Start
STEP Tag	Loop Start			INSERT MODIFY
LOOP END TAG				
003-Loop End				
LOOP CYCLES				
10				

1. **Description:** It makes repeated loop by a pair with "Loop End" step. OACIS repeats the steps wrapped with "Loop Start" and "Loop End" by the specified loop cycles.

- **Note #1:** It should be located before the paired "Loop End" step. It can't be located after "Loop End" step.
- **Note #2:** If there are multi loop cycles, the "Loop Start" step should be paired with the closest "Loop End" step. For example, if the first "Loop Start" is step number 3 and the second "Loop Start" is step number 4, and there are "Loop End"s at step number 10 and 11, the first "Loop Start" should be

paired with step number 10 "Loop End" step.

2. Parameters:

- **Loop End Tag:** Target "Loop End" step to be paired.
- **Loop Cycles:** The repeated cycles.
 - **Note:** If you input "0", the OACIS runs infinity loop.
- **Step Tag:**

H. Loop End

CONFIGURATION		MOVE	SIGNAL	SEQUENCE	MEASURE
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition	Jump by Multi Conditions	Loop Start
Loop End					
STEP Tag		<input type="text" value="Loop End"/>		INSERT	MODIFY

1. **Description:** It makes repeated loop by a pair with "Loop Start" step. See the "Loop Start" for more details.

2. Parameters:

- Step Tag:

I. Wait to DI

CONFIGURATION		MOVE	SIGNAL	SEQUENCE	MEASURE	ANAL
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition	Jump by Multi Conditions	Loop Start	Loop End
Wait to DI						
STEP Tag		<input type="text" value="Wait to DI"/>		INSERT	MODIFY	
DIGITAL INPUT Ch.		END CONDITION	TIME LIMIT (Sec)			
<input type="text" value="Digital Input #1"/>		ON	<input type="text" value="2"/>			

1. **Description:** Waiting for the selected Digital Input Signal. That is until a selected digital input channel have same condition, the step will wait for the condition in the present step.

2. Parameters:

- **Digital Input Ch.:** Digital Input Signal Channel
- **End Condition:** End condition to move on to next step. When the OACIS come in to this step, if the signal is already "End Condition", then move on to the next step without waiting. [On] or [Off].
- **Time Limit:** If there is no end condition signal within the specified "Time Limit", the OACIS send a error message and ends program. [sec] (0 ~ 99).
- **Step Tag:**

J. Delay

CONFIGURATION		MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition	Jump by Multi Conditions	Loop Start	Loop End
Wait to DI						
Delay						
STEP Tag		<input type="text" value="Delay"/>		INSERT	MODIFY	
DURATION [sec]						
<input type="text" value="1"/>						

1. **Description:** It makes like idle condition of OACIS. OACIS is doing nothing within the specified duration.

2. Parameters:

FUNCTION DESCRIPTION

- **Duration:** Time period while the OACIS is to be idle. [sec] (0 ~ 9999)
- **Step Tag:**

K. Wait to Pause

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	
Jump by Condition	Jump by Condition #2	Jump by Multi Conditions	Loop Start	Loop End	Wait to DI	Delay	Wait to Pause

STEP Tag INSERT MODIFY

TIME LIMIT (Sec)

Message Popup Disabled

None

- Description:** The step will wait for the Program Stop On signal during the Time Limit. You need to preset Program Start Mode as 1 in User Configuration before you start the program. To terminate this step and go to the next, Program Stop should be turned Off and then Program Start signal has to be pulsed.
- Parameters:**
 - **TIME LIMIT (Sec):** If there is no Program Stop signal within the specified "Time Limit", the OACIS send an error message and ends program. [sec] (0 ~ 99).
 - **Message Popup Disabled:** If OACIS meets this step, a message window pops up on the screen. The popup message shows up at the step and disappears going to the next automatically. [byte] (0 ~ 99).
 - **Step Tag:**

L. Program End

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE			
Jump Tag	Jump to Step	Jump to Step by DI	Jump by Condition	Jump by Multi Conditions	Loop Start	Loop End	Wait to DI	Delay	Program End

STEP Tag INSERT

- Description:** All programs should end with this function. You can't add or delete this function. And one program has only one program end step.
- Parameters:**
 - **Step Tag:**

V. MEASURE

A. Measure AI or Position

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	
Measure AI or Position	DAQ	DAQ2	DAQD	DAQA	CAPTURE

STEP Tag

ANALOG INPUT Ch. DURATION [sec] MEASURING MODE

GLOBAL VARIABLE to Save

Average

Variation

Min

Max

- Description:** Measure the current value of the selected Analog Input Channel or Axis Position then save it into the selected global variable.
- Parameters:**
 - Analog Input Ch.:** Target Analog Input Channel to measure.
 - Duration:** Time period to measure. If it is 0.002, OACIS captures only one value and save regardless of measuring mode. [sec] (0.002 ~)
 - Measuring Mode:** You can select one of "Average", "Variation", "Min" and "Max".
 - **Average:** Save the average of the measured values for the specified duration.
 - **Variation:** Save the variation (= Max – Min).
 - **Min:** Save the minimum value.
 - **Max:** Save the maximum value.
 - Global Variable to Save:** The global variable to save the measured value.
 - Step Tag:**

B. DAQ

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	
Measure AI or Position	DAQ	DAQ2	DAQD	DAQA	CAPTURE

STEP Tag

TARGET STEP

DAQ X Value DAQ Y Value

DAQ Sampling Rate DAQ From DAQ To

Acceptable Min. Sampling Rate (Reference Only)

0.0050

- Description:** Acquires the selected x and y analog signal data and save with the tag name while the selected target step is running. It is to be used for Analysis functions for graph view. You will be able to see the raw data of maximum 4,000 of (x, y) points.
 - Note:** DAQ step should be located before the target step.

FUNCTION DESCRIPTION

- **Note:** The number of all DAQs (DAQ, DAQ2, DAQD and DAQA) per one program is limited to **10**.

2. Parameters:

- **Target Step:** Target Step to acquire data.
- **DAQ X Value:** You can select one of Analog Input Channel or Time. If you select "Time", you will see the time frame curve.
- **DAQ Y Value:** You can select one of Analog Input Channel or Time.
- **Save or No Save:**
 - **Save:** DAQ and show the graph on the main screen.
 - **No Save:** Only DAQ without showing. You can still use it for Analysis functions.
- **DAQ Sampling Rate:** The rate to gather the data. It is for X values. If you select "Time" for X value and input 0.02 as Sampling Rate. The OACIS will gather the data every 0.02 seconds. If you select "Position" for X value and input 0.02 as sampling rate, OACIS will gather the data every 0.02mm. If you input "0" as sampling rate, OACIS will gather the data as many as possible.
 - **Note:** Maximum data size is 4,000. So you need to consider the rate, and DAQ range to see the reasonable result. For example, if the range is 1000 and the rate is 0.1, you will see the only first 400 range because of the limited size.
- **DAQ from:** The X range starting point to gather the data.
- **DAQ to:** The X range end point to gather the data.
- **Acceptable Min. Sampling Rate:** This can help you calculate Min sampling rate in the range of DAQ automatically. But it is only for reference. Users should put a proper value in DAQ sampling rate according to the real range of DAQ.
- **Step Tag:**

3. Example:

- Target Step: Move to Position of Axis #1. It moves from 0mm to 100mm. (it is servo press)
- DAQ X value: Axis Position (mm).
- DAQ Y value: Axis Load (kN).
- DAQ from: 10
- DAQ to: 90
- Sampling Rate: 0.2
- -> You will see around 400 points like (10, Load), (10.2, Load), (90, Load)

C. DAQ 2

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	
Measure AI or Position	DAQ	DAQ2	DAQD	DAQA	CAPTURE

STEP Tag

DAQ START STEP

DAQ END STEP

DAQ X Value DAQ Y Value

DAQ Sampling Rate DAQ From DAQ To

DAQ Time Delay (sec)

Acceptable Min. Sampling Rate (Reference Only)

1. **Description:** DAQ2 is similar to DAQ function except for selecting multi steps for data acquisition. It allows you to save multi steps data to a single curve by selecting “DAQ Start Step” and “DAQ End Step”.

- **Note:** DAQ2 step should be located before the target step.
- **Note:** The number of DAQs per one program is limited to 10.
- **Note:** Between “DAQ START STEP” and “DAQ END STEP” is not allowed to have specific functions like loop, jump involved with sequence.

2. **Parameters:**

- **DAQ START STEP:** Target Step to start acquiring data.
- **DAQ END STEP:** Target Step to finish acquiring data.
- **DAQ X Value:** You can select one of Analog Input Channel or Time. If you select “Time”, you will see the time frame curve.
- **DAQ Y Value:** You can select one of Analog Input Channels or Time.
- **Save or No Save:**
 - **Save:** Acquiring Data and show the graph on the main screen. DAQ graph file(*.gph) is to be saved in the local PC.
 - **No Save:** Acquiring Data without showing. Graph file will not be saved in the local PC. But it can be used in program for analysis.
- **DAQ Sampling Rate:** The rate to gather the data. It is for X values. If you select “Time” for X value and input 0.02 as Sampling Rate, OACIS will gather the data every 0.02 seconds. If you input “0” as sampling rate, OACIS will gather the data as many as possible.
 - **Note:** Maximum data size is 4,000. So you need to consider the rate, and DAQ range to see the reasonable result. For example, if the range is 1000 and the rate is 0.1, you will see the only first 400 range because of the limited size.
- **DAQ from:** The X range starting point to gather the data.
- **DAQ to:** The X range end point to gather the data.
- **DAQ Time Delay (sec):** You can set the time delay between each step. During this time delay, OACIS



- **Acceptable Min. Sampling Rate:** This can help you calculate Min sampling rate in the range of DAQ automatically. But it is only for reference. Users should put a proper value in DAQ sampling rate according to the real range of DAQ.

FUNCTION DESCRIPTION

● Step Tag:

3. Example:

DELETE	COPY	PASTE	CUT
STEP	FUNCTION	TAG	
001	Jump Tag	___INITIAL RESET___	
002	Reset All Global Variables	Reset All Global Variables	
003	Reset All DO	Reset All DO	
004	Set Status Binary	Set Status Binary	
005	Jump Tag	___DAQ___	
> 006	DAQ2	DAQ2	
007	Jump Tag	___MOVE___	
008	Move to Position	Move to Position by 100mm	
009	Delay	Delay 1 sec	
010	Move to Load	Move to Load by 1kN	
011	Move to Program Home	Move to Program Home	
012	Program End	Program End	

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	MATH
Measure AI or Position	DAQ	DAQ2					

STEP Tag: INSERT MODIFY

DAQ START STEP:

DAQ END STEP:

DAQ X Value: Yes SAVE

DAQ Y Value:

DAQ Sampling Rate: DAQ From: DAQ To:

DAQ Time Delay (sec):

- 'DAQ START STEP' should be located earlier than 'DAQ END STEP'.
- Above example shows the DAQ2 that saves data from step #008 (Move to Position by 100mm) through step #010 (Move to Load by 1kN).

D. DAQD

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	
Measure AI or Position	DAQ	DAQ2	DAQD	DAQA	CAPTURE

STEP Tag: INSERT MODIFY

TARGET DAQ:

Negative Delta X (or Y): Positive Delta X (or Y): No SAVE

MODE:

METHOD:

1. **Description:** You can get the “First Order Differential Curve” of the Target DAQ using this function.

- **Note:** DAQD step should be located after the target step of the Target DAQ.


STEP	FUNCTION	TAG
> 001	Move to Position	Move to Position 1
002	DAQ	DAQ
003	Move to Position	Move to Position 2
004	DAQD	DAQD
005	Move to Program H...	Move to Program Home
006	Program End	Program End

Located after “DAQ” and “Move to Position 2” that is target step of DAQ

2. Parameters:

- **Target DAQ:** Raw Data of the DAQD. DAQ (x, y) -> DAQD (x, $\delta y/\delta x$) with “delta X” mode or ($\delta x/\delta y$, y) with “delta Y” mode.
- **Negative Delta X (or Y) / Positive Delta X (or Y):** You can specify increment of δx (or δy). If you set -0.1 and +0.1 respectively, increment would be 0.2.
- **MODE:**
 - **Delta X:** OACIS will return differential curve (x, $\delta y/\delta x$).
 - **Delta Y:** OACIS will return differential curve ($\delta x/\delta y$, y).
- **METHOD:**
 - **Using Linear Regression:** OACIS calculates differential point using “Linear Regression” method. You will see more reasonable differential curve. But it takes longer time.
 - **Using Two End Points:** OACIS calculates differential point using only two end points of the increment range like $(y_2-y_1)/(x_2-x_1)$. In case, you will see unacceptable curve. But it is pretty faster than “Using Linear Regression” mode.
- **Save or No Save:**
 - **Save:** Acquiring Data and show the graph on the main screen. DAQ graph file(*.gph) is to be saved in the local PC.
 - **No Save:** Acquiring Data without showing. Graph file will not be saved in the local PC. But it can be used in program for analysis.
- **Step Tag:**

3. Example:



E. DAQA

CONFIGURATION		MOVE		SIGNAL		SEQUENCE		MEASURE	
Measure AI or Position		DAQ	DAQ2	DAQD	DAQA	CAPTURE			

STEP Tag

DAQ START STEP

DAQ END STEP

DAQ X Value DAQ Y Value

RANGE #1 DAQ From	RANGE #1 DAQ Sampling Rate	Estimated Samples Count
<input type="text" value="0.0000"/>	<input type="text" value="0.0200"/>	<input type="text" value="500"/>
RANGE #2 DAQ From	RANGE #2 DAQ Sampling Rate	
<input type="text" value="10.0000"/>	<input type="text" value="0.0100"/>	<input type="text" value="1000"/>
RANGE #3 DAQ From	RANGE #3 DAQ Sampling Rate	
<input type="text" value="20.0000"/>	<input type="text" value="0.0050"/>	<input type="text" value="2000"/>

DAQ To Estimated Samples Count (Total)

DAQ Time Delay (sec)


1. **Description:** You can specify three different sampling rate for three different range. And you can select multi steps as target like DAQ2.

- **Note:** DAQA step should be located before the target step.
- **Note:** The number of all DAQs (DAQ, DAQ2, DAQD and DAQA) per one program is limited to 10.
- **Note:** Between “DAQ START STEP” and “DAQ END STEP” is not allowed to have specific functions like loop, jump involved with sequence.

2. **Parameters:**

- **DAQ START STEP:** Target Step to start acquiring data.
- **DAQ END STEP:** Target Step to finish acquiring data.
- **DAQ X Value:** You can select one of Analog Input Channel or Time. If you select “Time”, you will see the time frame curve.
- **DAQ Y Value:** You can select one of Analog Input Channels or Time.
- **Save or No Save:**
 - **Save:** Acquiring Data and show the graph on the main screen. DAQ graph file(*.gph) is to be saved in the local PC.
 - **No Save:** Acquiring Data without showing. Graph file will not be saved in the local PC. But it can be used in program for analysis.
- **RANGE #1 DAQ Sampling Rate / RANGE #2 DAQ Sampling Rate / RANGE #3 DAQ Sampling Rate:** You can specify individual sampling rate of each range. For example, If you select “Time” for X value and input 0.02 as Sampling Rate, OACIS will gather the data every 0.02 seconds. If you select “Position” for X value and input 0.02 as sampling rate, OACIS will gather the data every 0.02mm. If you input “0” as sampling rate, OACIS will gather the data as many as possible.
 - **Note:** Maximum data size is 4,000. So you need to consider the rate, and DAQ range to see the reasonable result. For example, if the range is 1000 and the rate is 0.1, you will see the only first 400 range because of the limited size.
- **RANGE #1 DAQ from / RANGE #2 DAQ From / RANGE #3 DAQ From / DAQ To:** You can specify each DAQ range.
- **DAQ Time Delay (sec):** You can set the time delay between each step. During this time delay, OACIS does not acquire the data.
- **Estimated Samples Count:** This can help you calculate Min sampling rate in the range of DAQ automatically. But it is only for reference. Users should put a proper value in DAQ sampling rate according to the real range of DAQ. If sampling rates are too small, a warning message of “!!! Total SamplingRate is overflowed !!!” turns out.
- **Estimated Samples Count (Total):** Sum of every estimated samples count.
 - **Note:** When you put zero in sampling rate, a warning message of “!!! Total SamplingRate is overflowed !!!” turns out. However, you need to know that OACIS will still gather the data as many as possible.
- **Step Tag:**

3. **Example:**



FUNCTION DESCRIPTION

F. CAPTURE

CONFIGURATION		MOVE		SIGNAL		SEQUENCE		MEASURE
Measure AI or Position	DAQ	DAQ2	DAQD	DAQA	CAPTURE			
STEP Tag	CAPTURE				INSERT	MODIFY		
CAPTURING START STEP								
Move to Position								
CAPTURING END STEP								
Move to Position								
CAPTURE X Value				CAPTURE Y Value				
Axis#1 Position				Analog Input #1				
CAPTURING RANGE (of X) From				CAPTURING RANGE (of X) To				
0.0000				20.0000				
GLOBAL VARIABLE to Save X								
001;Global Variable #1								
GLOBAL VARIABLE to Save Y								
002;Global Variable #2								
CAPTURING MODE								
Maximum								

- Description:** You can get the Maximum (or Minimum) Y and X data without DAQ while the selected capturing steps are running. You can select multi steps as target like DAQ2. This function does not utilize DAQ for analysis because it returns the X and Y data just by a real-time comparison.

- **Note:** CAPTURE step should be located before the target step.

- Parameters:**

- **CAPTURING START STEP:** Target Step to start capturing data.
- **CAPTURING END STEP:** Target Step to finish capturing data.
- **CAPTURE X Value:** You can select one of Analog Input Channel or Time.
- **CAPTURE Y Value:** You can select one of Analog Input Channels or Time.
- **CAPTURING RANGE (of X) From:** Start point of the range to capture the data.
- **CAPTURING RANGE (of X) To:** End point of the range to capture the data.
- **GLOBAL VARIABLE to save X:** The global variable to save the X value captured until the capturing steps end.
- **GLOBAL VARIABLE to save Y:** The global variable to save the Y value captured until the capturing steps end.
- **CAPTURING MODE:** You can select one of "Minimum" and "Maximum".
 - **Minimum:** Save the minimum value during the capturing step.
 - **Maximum:** Save the maximum value during the capturing step.
- **Step Tag:**

G. Count DI

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	ME		
Measure AI or Position	DAQ	DAQ2	DAQD	DAQA	CAPTURE	Count DI
STEP Tag		Count DI		INSERT	MODIFY	
COUNTING START STEP						
===== Start Count DI						
COUNTING END STEP						
===== End Count DI						
Counting Range AI Ch.			Digital Input Ch to Count			
Axis#1 Position			Digital Input #1			
Counting Range (From)			Counting Range (To)			
0.0000			5.0000			
GLOBAL VARIABLE to Save Count						
001;Count DI						
Counting MODE			Rising Dead Time (sec)			
Rising Edge			0.0100			
			Falling Dead Time (sec)			
			0.0100			

1. **Description:** You can count the pulses of programmable digital inputs in the counting range of a selected AI channel while the steps specified from COUNTING START STEP to COUNTING END STEP are running. You can select the type of pulse in Counting MODE. Dead Time is for removing the signal noise of digital inputs.

- **Note:** Count DI step should be located before the target step.
- **Note:** You can use up to 10 Count DI functions per program and use them for the same target step as well.
- **Note:** Sampling frequency is 1kHz which means 1ms of sampling time.

2. **Parameters:**

- **COUNTING START STEP:** Target Step to start Count DI.
- **COUNTING END STEP:** Target Step to end Count DI.
- **Counting Range AI Ch.:** You can select one of Analog Input Channels or Time.
- **Digital Input Ch to Count:** Programmable input to be counted.
- **Counting Range (From):** Start point of the range to count DI signal.
- **Counting Range (To):** End point of the range to count DI signal.
- **GLOBAL VARIABLE to Save Count:** Global variable to save the DI value counted until the Count DI steps end.
- **Counting MODE:** You can select one of four options.
 - **Rising Edge:** Count the signal changing from low to high.
 - **Falling Edge:** Count the signal changing from high to low.
 - **Rising and Falling Edge:** Count the signal changes either way starting from low.
 - **Falling and Rising Edge:** Count the signal changes either way starting from high.
- **Rising Dead Time (sec):** High signals are supposed to be counted when the signal keeps “high” during the rising dead time consecutively from low.
- **Falling Dead Time (sec):** Low signals are supposed to be counted when the signal keeps “low” during the falling dead time consecutively from high.
- **Step Tag:**

FUNCTION DESCRIPTION

VI. ANALYSIS

: Analysis function is to analyze the data as a result of data acquisition (DAQ). And after the analysis, the result will restore to global variables.

Note: Analysis function should be located after target DAQ. That is to say, the step number of analysis function has more higher than the one of target DAQ. If it is located before the target DAQ, you will see the unexpected result.

A. Analysis MinMaxAve

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS
Analysis MinMaxAve	Analysis Turning Torque #1	Analysis Press #1	Analysis Press #2	Analysis Fx	Linear Regression
STEP Tag	Analysis MinMaxAve		INSERT	MODIFY	
TARGET DAQ	DAQ				
ANALYSIS RANGE From	0.0000		ANALYSIS RANGE To	0.0000	
GLOBAL VARIABLE to Save Min	001;Global Variable #1				
GLOBAL VARIABLE to Save Max	002;Global Variable #2				
GLOBAL VARIABLE to Save Average	003;Global Variable #3				
GLOBAL VARIABLE to Save Variation	004;Global Variable #4				

1. **Description:** Find Minimum value, Maximum value, Average value and Variation of the target DAQ then save them into the selected global variables.

2. **Parameters:**

- **Target DAQ:** Target DAQ for the analysis.
- **Analysis Range From:** Starting point of the range for the Analysis.
- **Analysis Range To:** End point of the range for Analysis.
 - DAQ Start Point < Analysis Start Point < Analysis End Point < DAQ End Point
- **Global Variable to Save Min:** Global Variable to save the Minimum value.
- **Global Variable to Save Max:** Global Variable to save the Maximum value.
- **Global Variable to Save Ave:** Global Variable to save the Average value.
- **Global Variable to Save Variation:** Global Variable to save the Variation (= Max – Min).
- **Step Tag:**


B. Analysis Turning Torque #1

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS
Analysis MinMaxAve	Analysis Turning Torque #1	Analysis Press #1	Analysis Press #2	Analysis Fx	Linear Regression
STEP Tag <input type="text" value="Analysis Turning Torque #1"/> INSERT MODIFY					
TARGET DAQ <input type="text" value="DAQ"/>					
PITCH	ANALYSIS RANGE #1	ANALYSIS RANGE #2	ANALYSIS RANGE #3		
<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>		
		INCLUDING RANGE #1	EXCLUDING RANGE #2		
GLOBAL VARIABLE to SAVE RESULTS (RANGE #1)					
MAX PEAK to VALLEY	<input type="text" value="001;Global Variable #1"/>				
OVERALL PEAK to VALLEY	<input type="text" value="002;Global Variable #2"/>				
MAX	<input type="text" value="004;Global Variable #4"/>				
MIN	<input type="text"/>				
AVERAGE	<input type="text"/>				
GLOBAL VARIABLE to SAVE RESULTS (RANGE #2)					
MAX PEAK to VALLEY	<input type="text"/>				
OVERALL PEAK to VALLEY	<input type="text"/>				
MAX	<input type="text"/>				
MIN	<input type="text"/>				
AVERAGE	<input type="text"/>				
GLOBAL VARIABLE to SAVE RESULTS (RANGE #3)					
MAX PEAK to VALLEY	<input type="text"/>				
OVERALL PEAK to VALLEY	<input type="text"/>				
MAX	<input type="text"/>				
MIN	<input type="text"/>				
AVERAGE	<input type="text"/>				

1. **Description:** Special function to analyze turning torque curve. You can find Max Peak to Valley, Overall Peak to Valley, Maximum, Minimum and Average of the specified range. You can specify three ranges.

2. **Parameters:**

- **Target DAQ:** Target DAQ for the analysis.
- **Pitch:** Tooth pitch for the analysis.
- **Analysis Range #1:** If you input 90deg, the first range would be from -90deg to +90deg.
- **Analysis Range #2:** If you input 180deg, the second range would be from -180deg to +180deg.
 - **Excluding Range #1 or Including Range #1:** If you select “Excluding” option, the second range would be from -180deg to -90deg and from +90deg to +180deg. And if you select “Including” option, the second range would be from -180deg to +180deg.
- **Analysis Range #3:** If you input 360deg, the third range would be from -360deg to +360deg.
 - **Excluding Range #2 or Including Range #2:** see the above.
- **Max Peak to Valley:** Max adjacent Peak to Valley of the specified range.
- **Overall Peak to Valley:** Variation of the range (= Max – Min).
- **Max:** Maximum value of the range.
- **Min:** Minimum value of the range.
- **Average:** Average of the range.
- **Step Tag:**



C. Analysis Press #1

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS
Analysis MinMaxAve	Analysis Turning Torque #1	Analysis Press #1	Analysis Press #2	Analysis Fx	Linear Regre
STEP Tag	Analysis Press #1	INSERT	MODIFY		
TARGET DAQ	DAQ				
NO DROP DISTANCE ANALYSIS					
NO DROP ANALYSIS RANGE From	0.0000	NO DROP ANALYSIS RANGE To	0.0000		
NO DROP INITIAL LOAD	0.0000	NO DROP ALLOWABLE LOAD DROP	0.0000		
GLOBAL VARIABLE to Save No Drop Distance	002;Global Variable #2				
MIN MAX AVERAGE ANALYSIS					
MIN MAX AVE ANALYSIS RANGE From	0.0000	MIN MAX AVE ANALYSIS RANGE To	0.0000		
GLOBAL VARIABLE to Save Min	002;Global Variable #2				
GLOBAL VARIABLE to Save Max	003;Global Variable #3				
GLOBAL VARIABLE to Save Average	004;Global Variable #4				


1. **Description:** Special function to analyze Pressing curve. It consists of two analyses. One is the analysis to find “No drop distance” and the other one is to find Min, Max and Average value.

2. **Parameters:**

- **Target DAQ:** Target DAQ for the analysis.
- **No Drop Analysis Range From:** Starting point of the range for the Analysis.
- **No Drop Analysis Range To:** End point of the range for the Analysis.
- **No Drop Initial Load:** Starting condition to monitor the “No Drop Distance”.
- **No Drop Allowable Load Drop:** If the load drop is bigger than this value, OACIS restart to monitor the “No Drop Distance”.

- Step Tag:

3. Example:




D. Analysis Press #2

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Analysis MinMaxAve	Analysis Turning Torque #1	Analysis Press #1	Analysis Press #2	Analysis Fx	Linear Regression	Linear Regression
STEP Tag Analysis Press #2		INSERT		MODIFY		
TARGET DAQ						
DAQ						
CONTACT LOAD	0.0000					
INSERTION RANGE	5.0000	~	10.0000			
MIN RUNNING LOAD RANGE	15.0000	~	30.0000			
MAX RUNNING LOAD RANGE	5.0000	~	30.0000			
BOTTOMING RANGE	30.0000	~	40.0000			
BOTTOMING CONDITION	Delta X 0.0100	Delta Y 0.1	Valid Points Qty 1	Load Direction Increase	Search Direction Increase	
CONTACT POSITION	100;Global Variable #100					
MAX INSERTION LOAD	100;Global Variable #100					
MAX INSERTION LOAD POSITION	100;Global Variable #100					
MIN RUNNING LOAD	100;Global Variable #100					
MIN RUNNING LOAD POSITION	100;Global Variable #100					
MAX RUNNING LOAD	100;Global Variable #100					
MAX RUNNING LOAD POSITION	100;Global Variable #100					
END POSITION	100;Global Variable #100					
END POSITION LOAD	100;Global Variable #100					
END POSITION LOAD DROP	100;Global Variable #100					
BOTTOMING POSITION	100;Global Variable #100					
BOTTOMING LOAD	100;Global Variable #100					
BOTTOMING MODE	100;Global Variable #100					
PRESS DEPTH	100;Global Variable #100					

FUNCTION DESCRIPTION

1. **Description:** A special function to analyze Pressing curve. You can get a lot of important information during the press by this function.
2. **Parameters:**
 - **Target DAQ:** Target DAQ for the analysis.
 - **Contact Load:** User input load to decide a contact point.
 - **Insertion Range:** Range to proceed with the insertion.

- **Min Running Load Range:** Range to keep over the minimum load during the press.
- **Max Running Load Range:** Range to keep under the maximum load during the press.
- **Bottoming Range:** OACIS finds “Bottoming Condition” only in this range.
- **Bottoming Condition**
 - : **Delta X / Delta Y / Valid Points Qty / Load Direction / Search Direction**
 - It is possible to put only positive numbers in both Delta X and Delta Y.
 - Delta Y can be used as a signal noise limit on a specific occasion.
 - Bottoming Condition is to be defined by five parameters, Delta X, Delta Y, Valid Points Qty, Load Direction and Search Direction. If the actual “ $\delta y/\delta x$ ” is greater than the specified “Delta Y / Delta X” consecutively in the number of times more than the specified “Valid Points Qty”, OACIS returns the first point of the first satisfied “ $\delta y/\delta x$ ” as the bottoming point.
 - When the load increases in a negative direction, you can select Load Direction as “decrease”. Even in this case, you should put the absolute value of Y displacement in Delta Y.
 - If you want to find the bottoming point backwards from the end position, you can choose Search Direction as “decrease”. It is useful when there are several bottoming points and if you want to find the last one.
- **Contact Position:** Position value at the Contact Load.
- **Max Insertion Load:** Maximum Load in the Insertion Range.
- **Max Insertion Load Position:** Position value at the Max Insertion Load.
- **Min Running Load:** Minimum load in the Min Running Load Range.
- **Min Running Load Position:** Position value at the Min Running Load.
- **Max Running Load:** Maximum load in the Max Running Load Range.
- **Max Running Load Position:** Position value at the Max Running Load.
- **End Position:** Position value at the end of the press.
- **End Position Load:** Load value at the End Position.
- **End Position Load Drop:** Difference between Max Load and End Position Load.
- **Bottoming Position:** Second position value of the first “ $\delta y/\delta x$ ” that is satisfied with the Bottoming Condition.
- **Bottoming Load:** Load value at the Bottoming Position.
- **Bottoming Mode:** It saves bottoming information to the selected global variable as below.
 - 1: Pass. OACIS found the bottoming condition in the bottoming range.
 - 2: Fail. OACIS failed to find the bottoming condition in the bottoming range. In this case, OACIS returns (0, 0) into the bottoming position.
- **Press Depth:** Difference between the Contact Position and the End Position.
- **Step Tag:**



E. Analysis Fx

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS
Analysis MinMaxAve	Analysis Turning Torque #1	Analysis Press #1	Analysis Press #2	Analysis Fx	Linear Regress

STEP Tag


TARGET DAQ

ANALYSIS RANGE From ANALYSIS RANGE To

'x' VALUE MODE

GLOBAL VARIABLE to Save Result

- Description:** The function is to return the y-crossed value or x-crossed value of the curve. There are two modes, f(x) and f(y).
- Parameters:**
 - **Target DAQ:** Target DAQ for the analysis.
 - **Analysis Range From:** Starting point of the range for the Analysis.
 - **Analysis Range To:** End point of the range for the Analysis.
 - **X or Y value:** It depends on the mode selection.
 - **f(x) or f(y):** You can select one of f(x) and f(y).
 - Ex: If the selected mode is f(x). And the input x value is 5. The function is to return $Y = f(5)$.
 - **Step Tag:**
- Example:**



FUNCTION DESCRIPTION

F. Linear Regression

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GA
Analysis MinMaxAve	Analysis Turning Torque #1	Analysis Press #1	Analysis Press #2	Analysis Fx	Linear Regression	
STEP Tag		Linear Regression	INSERT	MODIFY		
TARGET DAQ						
DAQ						
ANALYSIS RANGE From		0.0000	ANALYSIS RANGE To		0.0000	
GLOBAL VARIABLE to Save "a" (Slope)						
001;Global Variable #1						
GLOBAL VARIABLE to Save "b" (Y Intercept)						
002;Global Variable #2						


1. **Description:** It returns the "Slope" and "Y Intercept" of the Linear Regression Line that comes from the specified range of the Target DAQ.

- **Note:** This function should be located after target step of the target DAQ step. For example, if the target step of the Target DAQ is "Move to Load" with step #45, this function's step number should be later than 45. Target DAQ -> Move to Load (target step of the Target DAQ) -> Linear Regression. Otherwise, you will see the unexpected values.

2. Parameters:

- **Target DAQ:** Target DAQ for the analysis.
- **Analysis Range From:** Starting point of the range for the Analysis.
- **Analysis Range To:** End point of the range for the Analysis.
- **Global Variable to Save "a" (Slope):** The slope of the linear regression line formula ($Y = aX + b$) driven from the Target DAQ.
- **Global Variable to Save "b" (Y Intercept):** The Y Intercept of the linear regression line formula ($Y = aX + b$) driven from the Target DAQ.

3. Example:



G. Linear Regression #2

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAC
Analysis Turning Torque #1	Analysis Press #1	Analysis Press #2	Analysis Fx	Linear Regression	Linear Regression #2	

STEP Tag INSERT MODIFY

TARGET DAQ

ANALYSIS RANGE From ANALYSIS RANGE To

GLOBAL VARIABLE to Save "a" (Slope)

GLOBAL VARIABLE to Save "b" (Y Intercept)

GLOBAL VARIABLE to Save "R^2"

- Description:** It is same as "Linear Regression" Function except that it returns "R^2" as well. "R^2" represents reliability of "a" and "b". Please see the "Linear Regression" function for more details.

H. Find Cross Point

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS
Analysis Press #1	Analysis Press #2	Analysis Fx	Linear Regression	Linear Regression #2	Find Cross Point

STEP Tag INSERT MODIFY

TARGET REGRESSION LINE

ANALYSIS MODE

GLOBAL VARIABLE for 'X'

GLOBAL VARIABLE for 'Y'

SECOND REGRESSION LINE

- Description:** It returns the point (x,y) information of the crossed point between the selected "Linear Regression Line" and the other line per the selected mode. This step should be located after target regression line step.
- Parameters:**
 - **Target Regression Line:** Target Regression Line for the analysis.
 - **Analysis Mode**
 - **L: Find Cross Point with Second Line:** It returns the cross point (x, y) of two regression lines (Target Regression Line and Second Regression Line)
 - **X: Find 'Y' by the provided 'X':** It returns 'Y' value paired with the selected 'X' value on the Target Regression Line. It works like "Analysis Fx" function (with Fx mode).
 - **Y: Find 'X' by the provided 'Y':** It returns 'X' value paired with the selected 'Y' value on the Target Regression Line. It works like "Analysis Fx" function (with Fy mode).

FUNCTION DESCRIPTION

- **Global Variable for 'X'**: Global Variable to be used for 'X'.
- **Global Variable for 'Y'**: Global Variable to be used for 'Y'.
- **Second Regression Line**: Regression Line to find cross point.
- **Step Tag**:

I. Analysis Load Drop

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Analysis Press #1	Analysis Press #2	Analysis Fx	Linear Regression	Linear Regression #2	Find Cross Point	Analysis Load Drop

STEP Tag:

TARGET DAQ

ANALYSIS RANGE From	ANALYSIS RANGE To	MODE
<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	<input type="text" value="Increase"/>
LOAD DROP TO COUNT	SIGNAL NOISE LIMIT	
<input type="text" value="0.0000"/>	<input type="text" value="0.0000"/>	

GLOBAL VARIABLE to Save "Load Drop Count"

GLOBAL VARIABLE to Save "Max Load Drop"

- Description:** It returns the "Load Drop Count" and "Max Load Drop" per the input parameters and selected Mode.
- Parameters:**
 - **Target DAQ:** Target DAQ for the analysis.
 - **Analysis Range From:** Starting point of the analysis.
 - **Analysis Range To:** End point of the analysis.
 - **Mode**
 - **Increase:** It is finding "Load Drop".
 - **Decrease:** It is finding "Load Spike".
 - **Load Drop To Count:** OACIS is counting the number of Load Drop (or Spike) that is bigger than "Load Drop to Count".
 - **Signal Noise Limit:** OACIS ignores this load variation as Signal Noise.
 - **Global Variable to Save "Load Drop Count":** Global Variable to save "Load Drop Count".
 - **Global Variable to Save "Max Load Drop":** Global Variable to save "Max Load Drop".

J. Find Cross Point #2

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Analysis Press #2	Analysis Fx	Linear Regression	Linear Regression #2	Find Cross Point	Analysis Load Drop	Find Cross Point #2

STEP Tag INSERT MODIFY

TARGET DAQ

ANALYSIS RANGE From ANALYSIS RANGE To MODE (Search Direction)

- Increase
- Decrease

GLOBAL VARIABLE for "a" (Slope)

GLOBAL VARIABLE for "b" (Y Intercept)

GLOBAL VARIABLE to save "X" of cross point


GLOBAL VARIABLE to save "Y" of cross point

1. **Description:** It returns the crossed point (x, y) information between the selected DAQ curve and the Line created by the input "Slope" and "Y Intercept". If there are more than one crossed points, it returns the first point depending on the selected "Search Direction Mode".

2. **Parameters:**

- **Target DAQ:** Target DAQ for the analysis.
- **Analysis Range From:** starting point of the range for the analysis.
- **Analysis Range To:** end point of the range for the analysis.
- **Mode (Search Direction):**
 - **Increase:** It searches the cross point in the incremental direction.
 - **Decrease:** It searches the cross point in the decremental direction.
- **Global Variable for "a" (Slope):** The global variable to be used as "Slope" of the virtual line.
- **Global Variable for "b" (Y intercept):** The global variable to be used as "Y Intercept" of the virtual line.
- **Global Variable to save "X" of cross point:** The global variable to save "X" value of the crossed point.
- **Global Variable to save "Y" of cross point:** The global variable to save "Y" value of the crossed point.

3. **Example:**



If you select "Increase" as Search Direction Mode, it returns "Point #1". And if you select "Decrease", it returns "Point #2".

FUNCTION DESCRIPTION

K. Assign Analysis GV

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	MA
Analysis Fx	Linear Regression	Linear Regression #2	Find Cross Point	Analysis Load Drop	Find Cross Point #2	Assign Analysis GV	

STEP Tag

TARGET ANALYSIS

Analysis Range (From)

Analysis Range (To)

GLOBAL VARIABLE for Parameter #3

GLOBAL VARIABLE for Parameter #4

GLOBAL VARIABLE for Parameter #5

GLOBAL VARIABLE for Parameter #6

GLOBAL VARIABLE for Parameter #7

GLOBAL VARIABLE for Parameter #8

GLOBAL VARIABLE for Parameter #9

GLOBAL VARIABLE for Parameter #10

- Description:** It allows you to assign Analysis Parameters like “Range From” and “Range To” by using Global Variables dynamically. This step should be located just before the Target Analysis Step.
- Parameters:**
 - **Target Analysis:** Target Analysis to assign Global Variables for the Analysis.
 - **Global Variable for Parameter #1 ~ #10:** Global Variables to be used as the Analysis Parameters of the Target Analysis.
 - **Step Tag:**

3. Example:

Here is an example program. There are 7 steps.
 You set Global Variable1 as 10 and Global Variable as 50.

DELETE	COPY	PASTE	CUT
STEP	FUNCTION	TAG	
> 001	Set Global Variable	Set Global Variable 1	
002	Set Global Variable	Set Global Variable 2	
003	DAQ	DAQ	
004	Move to Load	Move to Load	
005	Assign Analysis GV	Assign Analysis GV	
006	Analysis MinMaxAve	Analysis MinMaxAve	
007	Program End	Program End	

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	MATH
Reset All Global Variables	Set Global Variable	Math1	Math2				

STEP Tag

GLOBAL VARIABLE TO SET

SET VALUE

DELETE	COPY	PASTE	CUT
STEP	FUNCTION	TAG	
001	Set Global Variable	Set Global Variable 1	
> 002	Set Global Variable	Set Global Variable 2	
003	DAQ	DAQ	
004	Move to Load	Move to Load	
005	Assign Analysis GV	Assign Analysis GV	
006	Analysis MinMaxAve	Analysis MinMaxAve	
007	Program End	Program End	


CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	MATH
Reset All Global Variables	Set Global Variable	Math1	Math2				

STEP Tag


GLOBAL VARIABLE TO SET

SET VALUE


Add “Analysis MinMaxAve” function with “Analysis Range From” and “To” set as zero.



You added “Assign Analysis GV” just before above “Analysis MinMaxAve” step. And select the “Analysis MinMaxAve” as Target Analysis. When you select the Target Analysis, you can see the Global Variable for Parameters Name Tags are changed to proper name. And by assigning “Global Variable #1” and “Global Variable #2” as the analysis range of the Target Analysis step, the “Analysis MinMaxAve” step will analyze within 10 to 50.



L. Find Point



1. **Description:** It returns the Minimum(or Maximum) point (x, y) in the selected target DAQ curve. You can also define your analysis range of the target DAQ.
2. **Parameters:**
 - **Target DAQ:** Target DAQ for the analysis.
 - **Analysis RANGE From:** Start point of the range for the analysis.
 - **Analysis RANGE To:** End point of the range for the analysis.
 - **Mode (Min or Max):**
 - **Minimum:** Save the minimum value in the target DAQ.
 - **Maximum:** Save the maximum value in the target DAQ.
 - **GLOBAL VARIABLE to save “X” of the Point:** The global variable to save the X value of the captured point whose Y is a Minimum or Maximum value.
 - **GLOBAL VARIABLE to save “Y” (Min or Max):** The global variable to save the Y value which is a Minimum or Maximum.
3. **Step Tag:**

FUNCTION DESCRIPTION

VII.GAGE

A. Gaging Global Variable

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Gaging Global Variable	Gaging AI or Position	Gaging Global Variable by Var	Check Global Variable	Gaging DAQ by Teaching		
STEP Tag	Gaging Global Variable		INSERT	MODIFY		
GLOBAL VARIABLE TO GAGE						
001;Global Variable #1						
LOWER LIMIT		UPPER LIMIT				
-1.0000		1.0000				
CASE: PASS						
STEP TO JUMP						
002-Pass						
SET STATUS BIN (-1: Don't Change Status Binary)				-1		
CASE: HIGH REJECT						
STEP TO JUMP						
003-High Reject						
SET STATUS BIN (-1: Don't Change Status Binary)				1		
CASE: LOW REJECT						
STEP TO JUMP						
004-Low Reject						
SET STATUS BIN (-1: Don't Change Status Binary)				2		

1. **Description:** Evaluate the selected global variable based on the lower limit and upper limit. Then set the Status Binary and jump to the selected step.

2. **Parameters:**

- **Global Variable to Gage:** The Global Variable to evaluate.
- **Lower Limit:** Lower Limit to pass.
- **Upper Limit:** Upper Limit to pass.
- **Case Pass:** In the case of that the selected Global Variable is no smaller than Lower Limit or no greater than Upper Limit.
 - **Step to Jump:** Target Step to Jump in the case of "Pass"
 - **Set Status Bin:** New value of the Status Bin before jump to the target step. If you input -1, jump to the target step without changing the Status Bin.
 - **Ex:** On the above picture, if the value is 0, it jumps to step 8 and set Status Binary as 1.
- **Case High Reject:** In the case of that the selected Global Variable is greater than Upper Limit.
 - **Step to Jump:** Target Step to Jump in the case of "High Reject"
 - **Set Status Bin:** New value of the Status Bin before jump to the target step. If you input -1, jump to the target step without changing the Status Bin.
 - **Ex:** On the above picture, if the value is 2, it jumps to step 006 and set Status Binary as 2.
- **Case Low Reject:** In the case of that the selected Global Variable is smaller than Lower Limit.
 - **Step to Jump:** Target Step to Jump in the case of "Low Reject"
 - **Set Status Bin:** New value of the Status Bin before jump to the target step. If you input -1, jump to the target step without changing the Status Bin.
 - **Ex:** On the above picture, if the value is -2, it jumps to step 007 and set Status Binary as 3.
- **Step Tag:**

B. Gaging AI or Position

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Gaging Global Variable	Gaging AI or Position	Gaging Global Variable by Var	Check Global Variable	Gaging DAQ by Teaching		
STEP Tag	Gaging AI or Position		INSERT	MODIFY		
ANALOG INPUT Ch. TO GAGE						
Analog Input #1						
LOWER LIMIT	UPPER LIMIT					
0.0000	2.0000					
CASE: PASS						
STEP TO JUMP						
002-Pass						
SET STATUS BIN (-1: Don't Change Status Binary)			-1			
CASE: HIGH REJECT						
STEP TO JUMP						
003-High Reject						
SET STATUS BIN (-1: Don't Change Status Binary)			3			
CASE: LOW REJECT						
STEP TO JUMP						
004-Low Reject						
SET STATUS BIN (-1: Don't Change Status Binary)			4			

- Description:** Evaluate the current value of the selected Analog Input Channel or Axis Position. The other function is same as “Gaging Global Variable”.

C. Gaging Global Variable by Var

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Gaging Global Variable	Gaging AI or Position	Gaging Global Variable by Var	Check Global Variable	Gaging DAQ by Teaching		
STEP Tag	Gaging Global Variable by Var		INSERT	MODIFY		
GLOBAL VARIABLE TO GAGE	001;Global Variable #1					
GLOBAL VARIABLE OF UPPER LIMIT	002;Global Variable #2					
GLOBAL VARIABLE OF LOWER LIMIT	003;Global Variable #3					
CASE: PASS						
STEP TO JUMP						
002-Pass						
SET STATUS BIN (-1: Don't Change Status Binary)			-1			
CASE: HIGH REJECT						
STEP TO JUMP						
005-Program End						
SET STATUS BIN (-1: Don't Change Status Binary)			1			
CASE: LOW REJECT						
STEP TO JUMP						
005-Program End						
SET STATUS BIN (-1: Don't Change Status Binary)			2			

- Description:** It is same as “Gaging Global Variable” except that the Lower Limit and Upper Limit are to be assigned by the selected global variables.(refer to the “Gaging Global Variable” for details)

FUNCTION DESCRIPTION

D. Check Global Variable


CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE
Gaging Global Variable	Gaging AI or Position	Gaging Global Variable by Var	Check Global Variable	Gaging DAQ by Teaching		
STEP Tag	Check Global Variable	INSERT	MODIFY			
GLOBAL VARIABLE TO CHECK	001;Global Variable #1					
VALUE TO COMPARE	1.0000					
CASE: EQUAL						
STEP TO JUMP	001-Move to Position by Var					
SET STATUS BIN (-1: Don't Change Status Binary)	-1					
CASE: NOT EQUAL						
STEP TO JUMP	005-Program End					
SET STATUS BIN (-1: Don't Change Status Binary)	3					

- Description:** Compare the selected global variable with custom input value then set the Status Binary and jump to the selected step.
- Parameters:**
 - **Global Variable to Check:** The Global Variable to compare.
 - **Value to Compare:** Custom input value to be compared with the selected global variable.
 - **Case Equal:** The case of that the selected Global Variable is equal to the custom input value.
 - **Step to Jump:** Target Step to Jump in the case of "Equal"
 - **Set Status Bin:** New value of the Status Bin before jump to the target step. If you input -1, jump to the target step without changing the Status Bin.
 - **Case Not Equal:** The case of that the selected Global Variable is different from the custom input value.
 - **Step to Jump:** Target Step to Jump in the case of "Not Equal"
 - **Set Status Bin:** New value of the Status Bin before jump to the target step. If you input -1, jump to the target step without changing the Status Bin.
- Step Tag:**

E. Gaging DAQ by Teaching


CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	MATH
Gaging Global Variable	Gaging AI or Position	Gaging Global Variable by Var	Check Global Variable	Gaging DAQ by Teaching			
STEP Tag		Gaging DAQ by Teaching	INSERT	MODIFY			
DAQ TO GAGE	DAQ						
UPPER LIMIT TEACHING CURVE	01:None						
LOWER LIMIT TEACHING CURVE	02:None						
GAGING RANGE	10.0000	~	20.0000				
CASE: PASS							
STEP TO JUMP	003-Pass						
SET STATUS BIN (-1: Don't Change Status Binary)			-1				
CASE: HIGH REJECT							
STEP TO JUMP	004-High Reject						
SET STATUS BIN (-1: Don't Change Status Binary)			1				
CASE: LOW REJECT							
STEP TO JUMP	005-Low Reject						
SET STATUS BIN (-1: Don't Change Status Binary)			2				
CASE: BOTH (HIGH & LOW) REJECT							
STEP TO JUMP	006-Program End						
SET STATUS BIN (-1: Don't Change Status Binary)			3				

- Description:** It evaluates the selected DAQ based on the lower limit Teaching Curve and the upper limit Teaching Curve. Then, it sets the Status Binary and jumps to the selected step. You can gage the whole DAQ curve within the specified range not just one point by using this function. Lower Limit Teaching Curve and Upper Limit Teaching Curve make a window to evaluate the selected DAQ curve.
- Parameters:**
 - **DAQ to Gage:** The DAQ to evaluate.
 - **Lower Limit Teaching Curve:** Lower Limit to pass. "00:No Limit" option is also available.
 - **Upper Limit Teaching Curve:** Upper Limit to pass. "00:No Limit" option is also available.
 - **Gaging Range:** The range to be evaluated.
 - **Case Pass:**




FUNCTION DESCRIPTION


● Case High Reject:



● Case Low Reject:





● Case Both (High and Low) Reject:




3. **How to Make Teaching Curve:** Here we describes on “How to make Teaching Curves” that would be used “Gaging DAQ by Teaching” function.

- Save Reference DAQ curve with *.gph file format by running the proper cycle.
- Open “TEACHING DAQ CURVE” window by clicking the menu. It requires Password input.





- Open DAQ as Reference Curve (From PC)



FUNCTION DESCRIPTION

● Create Teaching Curve #A

Teaching Curve #A Raw Data

TEACHING CURVE DATA #1	TEACHING CURVE DATA #2
X	Y
0.001	2.6456
0.002	2.6479
0.003	2.6498
0.004	2.6513
0.005	2.6531
0.006	2.6541
0.007	2.6556
0.008	2.657
0.009	2.6564
0.01	2.6571
0.011	2.6569
0.012	2.6565
0.013	2.6565
0.014	2.6563
0.015	2.6556
0.016	2.6551
0.017	2.6549
0.018	2.6552

● Create Teaching Curve #B

Teaching Curve #B Raw Data

TEACHING CURVE DATA #1	TEACHING CURVE DATA #2
X	Y
0.001	2.6456
0.002	2.6479
0.003	2.6498
0.004	2.6513
0.005	2.6531
0.006	2.6541
0.007	2.6556
0.008	2.657
0.009	2.6564
0.01	2.6571
0.011	2.6569
0.012	2.6565
0.013	2.6565
0.014	2.6563
0.015	2.6556
0.016	2.6551
0.017	2.6549
0.018	2.6552

FUNCTION DESCRIPTION

- Modify (delete / insert / change) the Raw Data manually as well.

Press Refresh Curve #A button

Revised Teaching Curve #A

Delete some specific range of data

TEACHING CURVE DATA #1	TEACHING CURVE DATA #2		
X	Y	X	Y
0.85	3.532	0.001	-1.3544
0.851	3.5311	0.002	-1.3521
0.852	3.5306	0.003	-1.3502
0.853	3.5303	0.004	-1.3487
0.854	3.53	0.005	-1.3469
0.854	3.53	0.006	-1.3459
0.858	3.5307	0.007	-1.3444
0.859	3.5307	0.009	-1.3436
0.86	3.5307	0.011	-1.3431
0.861	3.5298	0.012	-1.3435
0.862	3.5299	0.013	-1.3435
0.863	3.5293	0.014	-1.3437
0.864	3.5289	0.015	-1.3444
0.865	3.5282	0.016	-1.3449
0.866	3.5276	0.017	-1.3451
0.867	3.5273	0.018	-1.3448

- Offset Curve #A or Curve #B as X and Y values.

Offset by 0.5

Offset by -1

TEACHING CURVE DATA #1	TEACHING CURVE DATA #2		
X	Y	X	Y
0.501	2.6456	0.001	-2.3544
0.502	2.6479	0.002	-2.3521
0.503	2.6498	0.003	-2.3502
0.504	2.6513	0.004	-2.3487
0.505	2.6531	0.005	-2.3469
0.506	2.6541	0.006	-2.3459
0.507	2.6556	0.007	-2.3444
0.508	2.657	0.008	-2.343
0.509	2.6564	0.009	-2.3436
0.51	2.6571	0.01	-2.3429
0.511	2.6569	0.011	-2.3431
0.512	2.6565	0.012	-2.3435
0.513	2.6565	0.013	-2.3435
0.514	2.6563	0.014	-2.3437
0.515	2.6556	0.015	-2.3444
0.516	2.6551	0.016	-2.3449
0.517	2.6549	0.017	-2.3451
0.518	2.6552	0.018	-2.3448

FUNCTION DESCRIPTION

- Save Teaching Curve #A as the assigned Teaching Curve Number and Name.

	TEACHING NO.	TEACHING CURVE NAME TO SAVE
SAVE CURVE #A as	1	Teaching Curve1
SAVE CURVE #B as	2	Teaching Curve2

- Save Teaching Curve #B as the assigned Teaching Curve Number and Name

	TEACHING NO.	TEACHING CURVE NAME TO SAVE
SAVE CURVE #A as	1	Teaching Curve1
SAVE CURVE #B as	2	Teaching Curve2

- Then you can use the saved Teaching Curve at the “Gaging DAQ by Teaching” function.

VIII. MATH

A. Reset All Global Variables

CONFIGURATION	MOVE	SIGNAL			SEQUENCE		
Reset All Global Variables	Set Global Variable	Math1	Math2	Math3	Math4	MathA	Slope

STEP Tag INSERT MODIFY

- Description:** Reset All Global Variables (excluding "System Variables") as Zero.
- Parameters:**
 - Step Tag:**

B. Set Global Variable

CONFIGURATION	MOVE	SIGNAL			SEQUENCE		
Reset All Global Variables	Set Global Variable	Math1	Math2	Math3	Math4	MathA	Slope

STEP Tag INSERT MODIFY

GLOBAL VARIABLE TO SET

SET VALUE

- Description:** Set the selected Global Variable as the input value.
- Parameters:**
 - Global Variable to Set:** Global Variable to set as new value.
 - Set Value:** New value for the selected Global Variable.
 - Step Tag:**

C. Set Multi GVs

CONFIGURATION	MOVE	SIGNAL	SEQUENCE			ME
Reset All Global Variables	Set Global Variable	Set Multi GVs	Math1	Math2	Math3	Math4

STEP Tag INSERT MODIFY

GLOBAL VARIABLE TO SET	SET VALUE
<input type="text" value="001;Global Variable #1"/>	<input type="text" value="1.0000"/>
<input type="text" value="002;Global Variable #2"/>	<input type="text" value="2.0000"/>
<input type="text" value="003;Global Variable #3"/>	<input type="text" value="3.0000"/>
<input type="text" value="004;Global Variable #4"/>	<input type="text" value="4.0000"/>
<input type="text" value="005;Global Variable #5"/>	<input type="text" value="5.0000"/>

- Description:** It is same as "Set Global Variable" except that you can set a number of GVs at the same time. It is useful to classify GVs such as Constants, Gaging Limits and Target Positions.
- Parameters:**
 - Global Variable to Set:** Global Variables to set as new values. You can set Max. 12 GVs.
 - Set Value:** New values for the selected Global Variables.
 - Step Tag:**

FUNCTION DESCRIPTION

D. Math1

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE			
Reset All Global Variables	Set Global Variable	Math1	Math2	Math3	Math4	MathA	Slope

STEP Tag

GLOBAL VARIABLE #1
 =

GLOBAL VARIABLE #2
 GLOBAL VARIABLE #3

- Description:** You can do the four fundamental arithmetic operations by using this function. You need to select three Global Variables and one of the eight operations.
- Parameters:**
 - +, -, *, /, %(remainder), &(quotient), R(root), ^(square).
- Example:**
 - **IF**
 - Global Var#2 = 2
 - Global Var#3 = 3
 - **The results are the same as below,**
 - $GV1 = GV2 \% GV3 = 2 \% 3 = 2$
 - $GV1 = GV2 \& GV3 = 2 \& 3 = 0$
 - $GV1 = GV2 R GV3 = 2 R 3 = 1.2599$
 - $GV1 = GV2 ^ GV3 = 2 ^ 3 = 8$

E. Math2

CONFIGURATION	MOVE	SIGNAL	SEQUENCE				
Reset All Global Variables	Set Global Variable	Math1	Math2	Math3	Math4	MathA	Slope

STEP Tag

Y = aX + b

Y

a

X

b

Y LIMIT

- Description:** You can do calculate an equation of the first degree like $Y = aX + b$. You need to select each global variable for Y, a, X and B.

- **Example: Global Var#1** = Global Var#2 x Global Var#3 + Global Var#4.
- **Y Limit:** The result can't be over "Y Limit". If the result is 5 and "Y Limit" is 4, this function returns 4 instead of 5.

F. Math3

Reset All Global Variables Set Global Variable Math1 Math2 **Math3** Math4 MathA Slope Round

STEP Tag **INSERT** **MODIFY**

GLOBAL VARIABLE #1 <input type="text" value="001;Global Variable #1"/>	=	
GLOBAL VARIABLE #2 <input type="text" value="002;Global Variable #2"/>		GLOBAL VARIABLE #3 <input type="text" value="003;Global Variable #3"/> +
GLOBAL VARIABLE #4 <input type="text" value="100;Global Variable #100"/>		GLOBAL VARIABLE #5 <input type="text" value="100;Global Variable #100"/> +
GLOBAL VARIABLE #6 <input type="text" value="100;Global Variable #100"/>		GLOBAL VARIABLE #7 <input type="text" value="100;Global Variable #100"/> +
GLOBAL VARIABLE #8 <input type="text" value="100;Global Variable #100"/> +		GLOBAL VARIABLE #9 <input type="text" value="100;Global Variable #100"/> +
GLOBAL VARIABLE #10 <input type="text" value="100;Global Variable #100"/> +		GLOBAL VARIABLE #11 <input type="text" value="100;Global Variable #100"/>

1. **Description:** You can do calculate with 10 operands and 9 operators.

2. **Parameters:**

- +, -, *, /, %(remainder), &(quotient), R(root), ^(square).

3. **Example:**

● **IF**

- Global Var#2 = 2
- Global Var#3 = 3
- ...
- Global Var#11 = 11

● **And If you set as below,**

- $GV1 = GV2 + GV3 * GV4 - GV5 + GV6 + GV7 + GV8 + GV9 + GV10 + GV11$
- $GV1 = 2 + 3 * 4 - 5 + 6 + 7 + 8 + 9 + 10 + 11 = 66$
- OACIS returns **66** for Global Var#1.
- It is calculating sequentially. It does not follow general mathematics rules.
- $2 + 3 = 5 \rightarrow 5 * 4 = 20 \rightarrow 20 - 5 = 15 \rightarrow 15 + 6 + 7 + 8 + 9 + 10 + 11 = 66$

● **And If you set as below,**

- $GV1 = GV2 R GV3 ^ GV4 \% GV5 * GV6 \& GV7 + GV8 / GV9 + GV10 + GV11$
- $GV1 = 2 R 3 ^ 4 \% 5 * 6 \& 7 + 8 / 9 + 10 + 11 = 22$
- OACIS returns **22** for Global Var#1.
- $2 R 3 = 1.2599 \rightarrow 1.2599 ^ 4 = 2.5198 \rightarrow 2.5198 \% 5 = 2 \rightarrow 2 * 6 = 12 \rightarrow 12 \& 7 = 1 \rightarrow 1 + 8 = 9 \rightarrow 9 / 9 = 1 \rightarrow 1 + 10 + 11 = 22$

FUNCTION DESCRIPTION

G. Math4

Reset All Global Variables	Set Global Variable	Math1	Math2	Math3	Math4	MathA	Slope
----------------------------	---------------------	-------	-------	-------	--------------	-------	-------

STEP Tag

GLOBAL VARIABLE #1 INCREMENTAL VALUE

- Description:** You can easily increase a global variable as many as the incremental value. It is the same as $GV \#1 = GV \#1 + \text{Incremental Value}$.
- Parameters:**
 - Incremental value could be Positive or Negative.
- Example:**
 - If $GV \#1 = 3$, Incremental Value = -1, then $GV \#1 = 2$ for the first trial, $GV \#1 = 1$ for the second trial and $GV \#1 = 0$ for the third trial.

H. MathA

Reset All Global Variables	Set Global Variable	Math1	Math2	Math3	Math4	MathA	Slope
----------------------------	---------------------	-------	-------	-------	-------	--------------	-------

STEP Tag

y = f (x)

y

f

x Radian Degree

- Description:** You can calculate trigonometric and absolute function with a radian or degree unit.
- Parameters**
 - Sine / Cosine / Tangent / Absolute**
- Example:**
 - If you select Sine, Radian and $GV \#2 = 1$, then OACIS returns 0.8415 in $GV \#1$.
 - If you select Cosine, Degree and $GV \#2 = 360$, then OACIS returns 1 in $GV \#1$.
 - If you select Absolute and $GV \#2 = -2$, then OACIS returns 2 in $GV \#1$.

I. Slope

Reset All Global Variables	Set Global Variable	Math1	Math2	Math3	Math4	MathA	Slope
----------------------------	---------------------	-------	-------	-------	-------	-------	-------

STEP Tag

$y = (y2 - y1) / (x2 - x1)$

y

x1

y1

x2

y2

- Description:** You can easily calculate the slope between two points. Of course, you can also find the slope by using other Math functions.
- Example:**
 - If $(x1, y1) = (1, 1)$ and $(x2, y2) = (2, 3)$, then OACIS returns 2 in GV #1.

J. Round

Reset All Global Variables	Set Global Variable	Math1	Math2	Math3	Math4	MathA	Slope	Round
----------------------------	---------------------	-------	-------	-------	-------	-------	-------	-------

STEP Tag

GLOBAL VARIABLE TO ROUND

PLACE TO ROUND

- Description:** You can round a real number according to place to round.
- Example:**
 - If GV #1 = 1234.5678 and Place to Round = 3, then OACIS returns 1234.568 in GV #1.
 - If GV #1 = 1234.5678 and Place to Round = 0, then OACIS returns 1235 in GV #1.
 - If GV #1 = 1234.5678 and Place to Round = -2, then OACIS returns 1200 in GV #1.

FUNCTION DESCRIPTION

K. Find GV

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS				
Reset All Global Variables	Set Global Variable	Math1	Math2	Math3	Math4	MathA	Slope	Round	Find GV

STEP Tag

GLOBAL VARIABLE RESULT

GLOBAL VARIABLE #1 GLOBAL VARIABLE #2

MODE

GLOBAL VARIABLE SELECTION OPTION

1. **Description:** You can find a specific value to be satisfied with one of the five modes in the range of global variable selection option.

2. **Parameters:**

● **MODE:**

- **Max:** Maximum Value of the range.
- **Min:** Minimum Value of the range.
- **Ave:** Average Value of the range.
- **Variation:** Difference between Max and Min of the range
- **Median:** Value of the mid GV in the range. In case of Two Values Only in GLOBAL VARIABLE SELECTION OPTION, OACIS returns average value of the two GVs. In case of Including All Values between Two Values, OACIS returns value of the mid GV if the number of GVs in the range is odd and returns average value of the two mid GVs if even.

● **GLOBAL VARIABLE SELECTION OPTION:**

- **Two Values Only:** Selected two GVs. It means that the number of valid GVs is 2.
- **Including All Values Between Two Values:** All values between the selected two GVs. The number of valid GVs can be more than 2.

3. **Example:**

- Assume that GV#10=10, GV#11=11, GV#12=20, GV#13=13, GV#14=14, GV#15=15.
 - If you select "GV#10" in GLOBAL VARIABLE #1, "GV#15" in GLOBAL VARIABLE #2 and "**Max**" mode, then the result is **15** in "Two Values Only" option and **20** in "Including All Values Between Two Values".
 - If you select "GV#10" in GLOBAL VARIABLE #1, "GV#15" in GLOBAL VARIABLE #2 and "**Variation**" mode, then the result is **5** in "Two Values Only" option and **10** in "Including All Values Between Two Values".
 - If you select "GV#10" in GLOBAL VARIABLE #1, "GV#14" in GLOBAL VARIABLE #2 and "**Median**" mode, then the result is **12.5** in "Two Values Only" option and **20** in "Including All Values Between Two Values".

IX. FIELDBUS

A. Capture Serial From Fieldbus

CONFIGURATION	MOVE	SIGNAL	SEQUENCE	MEASURE	ANALYSIS	GAGE	MATH	FIELDBUS
Capture Serial From Fieldbus								
STEP Tag	<input type="text" value="Capture Serial"/>	INSERT	MODIFY					

1. **Description:** OACIS reads serial numbers stored in ASCii at this function step.
2. **Parameters:**
 - **Step Tag:**

REVISION

v1.00: Engineering Released

v1.40:

- Added "Assign Analysis GV" function (VI.I)

v1.41:

- Added "Move to Load by Var. #2" function (II.M)
- Added "Set AI or Position by Var." function (III.H)
- Added "Set As Abs Value by Var." function (III.I)

v1.51:

- Added "Move to Position with Limited Load" function (II.N)
- Added "Send Out Data" function (III.J)
- Added "DAQD" function (V.D)
- Added "Linear Regression #2" function (VI.J)
- Added "Math3" function (VIII.E)

v1.52:

- Added "DAQA" function (V.E)

v1.53:

- Added "Start Hold Load" / "End Hold Load" functions (II.O)

v1.54:

- Added "Move to Position by Var #2" function (II.H)
- Added "CAPTURE" function (V.F)
- Added "Find Point" function (VI.K)

v1.55:

- Updated "Document Format"

v1.56:

- Updated "Document Format".

v1.57:

- Updated "All function images" (II, III, IV, V, VI, VII, VIII)
- Added "Two Error and Stop buttons in Move to AI" (II.K)
- Added "Jump by Condition" function (IV.D)
- Added "Jump by Multi Conditions" function (IV.E)
- Added "Acceptable Min. Sampling Rate in DAQ" (V.B)
- Added "Acceptable Min. Sampling Rate in DAQ2" (V.C)
- Added "Estimated Samples Count in DAQA" (V.E)
- Added "Analysis Press #2" function (VI.D)
- Updated "Gaging DAQ by Teaching" function (VII.E)
- Added "%R^ in Math1" (VIII.C)
- Added "%R^ in Math3" (VIII.E)
- Added "Math4" function (VIII.F)
- Added "MathA" function (VIII.G)
- Added "Slope" function (VIII.H)
- Added "Round" function (VIII.I)
- Added "Find GV" function (VIII.J)

v1.58:

- Updated "Move to Position with Limited Load" function (II.O)
- Added "Deactivate" function (II.Q)

v1.59:

- Updated "Headers & Footers" format

v1.60:

- Updated "Image Size & Resolution"

v1.61:

- Added "Count DI" function (V.G)

v1.62:

- Added "Jump by Condition #2" function (IV.E)
- Added "Set Multi GVs" function (VIII.C)

v1.63:

- Revised "All Damaged Images"

v1.64:

- Updated "Start Hold Load / End Hold Load" function (II.P)

v1.65:

- Updated "Analysis Press #2" function (VI.D)

v1.66:

- Revised "CAPTURE" function (V.F)

v1.67:

- Added "Wait to Pause" function (IV.K)
- Downsized "All contents"

v1.68:

- Added "Move to Load by Var #3" function (II.R)

v1.69:

- Modified "Move to AI" function (II.K) Typo
- Added "Fieldbus In & Out" (I.C)
- Added "Capture Serial From Fieldbus" function (IX.A)

v1.70:

- Added "Caution" (II. I)

v1.71:

- Page format Updated